Meteorological Monitoring on Bikini Atoll: System Description and Data Summary (May 2000–April 2001)

Frank Gouveia, Rayla Bradsher, James Brunk, William Robison, and Terry Hamilton

U.S. Department of Energy



January 2002

DISCLAIMER

This document was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.

This work was performed under the auspices of the U. S. Department of Energy by the University of California, Lawrence Livermore National Laboratory under Contract No. W-7405-Eng-48.

This report has been reproduced directly from the best available copy.

Available to DOE and DOE contractors from the Office of Scientific and Technical Information P.O. Box 62, Oak Ridge, TN 37831 Prices available from (423) 576-8401 http://apollo.osti.gov/bridge/

Available to the public from the National Technical Information Service U.S. Department of Commerce 5285 Port Royal Rd., Springfield, VA 22161 http://www.ntis.gov/

OR

Lawrence Livermore National Laboratory Technical Information Department's Digital Library http://www.llnl.gov/tid/Library.html

Meteorological Monitoring on Bikini Atoll: System Description and Data Summary(May 2000 – April 2001)

Frank Gouveia
Rayla Bradsher
James Brunk
William Robison
Terry Hamilton

Manuscript Date: January 2002

Lawrence Livermore National Laboratory

University of California · Livermore, CA · 94551



Table of Contents

Introduction	1
System Description	1
System Description	
Sensors	
Manual Ran Gauge	
Data Logger	
DAPS	
D111 3	
Procedures	2
Inventory of Sensors	
Calibration of Sensors	
Wind Speed	
Wind Direction	
Temperature	
Relative Humidity	
Solar	
Rain Gauge	
Installation of Sensors	
Data Recovery	
Via Satellite	
On Site	6
Monthly Files	6
Annual Files	6
Summary of 2000–2001 Data	
Mission and Station Reports	
Spring 2000 Mission	
Spring 2001 Mission	
House 36	
Control Plot	
Eneu	
Historical Rainfall Data	8
Dainfall Circa Mary 2000	11
Rainfall Since May 2000	11
Wind Speed	10
White Speed	12
Monthly Average Wind Speed	12
Tionally Tiverage (That opeca	± <u>-</u>
Monthly Average Air Temperature	
The state of the s	
Annual Windrose	14
Summary 15	
·	
Acknowledgment	15
References	

Appendix A. Wiring Diagrams	16
Appendix B. Logger Programs	18
Appendix C. FORTRAN Code to Interpret 3-Character Data	
Appendix E. Monthly Tables of Daily Rainfall	74
Appendix F. Historical Monthly Totals of Rainfall.	87
Appendix G. Wind Rose Tables	93
List of Tables	
Table 1. Brief description of the meteorological stations currently located on Bikini Atoll	2
Table 2. List of variables measured at each station and the type of sensors used	3
Table 3. List of sensors used by the Marshall Islands Program	5
Table 4. Interpretation of the DAPS download message string.	7
Table 5. Historical values of the annual total rain (inches) for the Bikini Atoll gauges	g
Table 6. Historical values of monthly average rain (inches) for Bikini Atoll gauges.	11
List of Figures	
Figure 1. Map of Bikini Island with the locations of meteorological stations.	2
Figure 2. Map of Eneu Island with the location of the meteorological station.	2
Figure 3. Comparison of Relative Humidity as measures at the Control Plot and House 36 stations	9
Figure 4. Annual total rainfall for the year 1985 through 2000 from the Bikini Island average.	10
Figure 5. Monthly average of rain based on the best estimate of all Bikini Island data	10
Figure 6. Cumulative daily values of rainfall for the six rain gauges on Bikini Atoll for the period starting 6 May 2000 through 30 April 2001.	12
Figure 7. Histogram of cumulative frequency of wind speed class using all available data from May 2000 through April 2001	13
Figure 8. The monthly average wind speed from three Bikini Atoll stations	13
Figure 9. The monthly average air temperature from three Bikini Atoll stations, and the monthly maximum and minimum temperature from the Control Plot station.	14

Meteorological Monitoring on Bikini Atoll: System Description and Data Summary (May 2000 - April 2001)

Frank Gouveia, Rayla Bradsher, Jim Brunk, William Robison and Terry Hamilton

Introduction

Meteorological data are continuously collected at three sites on Bikini Atoll in support of radioecological research and monitoring programs conducted by the Health and Ecological Assessments Division at the Lawrence Livermore National Laboratory (LLNL). Weather stations were first established on Bikini Atoll in April 1990, and provide information on rainfall, wind speed and direction, air temperature, humidity, and solar radiation. These data and information are used to interpret results of remediation experiments designed to evaluate the effectiveness of potassium fertilizer on reducing the uptake of ¹³⁷Cs into locally grown foods. We have also demonstrated that 137Cs is slowly leached from surface soil by the action of rain water. Long-term meteorological data are crucial to our efforts of developing an understanding of environmental processes controlling the environment loss of 137Cs in coral atoll soil.

In May 2000, older data collection platforms

and the DOS-based system that downloaded data from National Oceanic & Atmospheric Administration (NOAA)'s Data Automatic Processing System (DAPS) was decommissioned, and new data loggers, GOES (Geostationary Operational Environmental Satellite) transmitters and antennas were installed. Consequently, new procedures were developed to maintain the field systems, download the data, and reduce and archive the data.

This document provides an operational description and status report on the three new meteorological monitoring systems on Bikini Atoll as well as an computational summary of previously recorded data. Included are overviews of procedures for sensor exchange, data recovery and reduction, and specific information about the different sensors. We also provide a description of systems maintenance and trouble shooting activities. This report will be updated on an annual basis.

System Description

Locations

Currently, there are three stations on Bikini Atoll: two on Bikini Island and one on Eneu Island (Table 1). The locations were chosen several years ago, and are good representations of meteorological conditions over the land surface.

As typical for a Pacific Ocean atoll, the topography around the meteorological stations is very level. The primary obstruction to the ambient airflow would come from the mature coconut trees (7-10 meters) and underbrush. The prevailing trade winds come from the ENE (about 70°), and this is considered the upwind direction in this paper. Figure 1 is a map of Bikini Island showing the locations of the Control Plot and House 36 stations. The Eneu station is shown in Figure 2, which is a map of Eneu Island.


The immediate surface near the Control Plot station is covered with short grasses. The closest trees are 8 m from the tower towards the North and West, and about 50 m to the East.

Although the House 36 station is near the lagoon, it is about 150 m in the downwind direction from the tree line. The area around House 36 features sandy soil surfaces and very little vegetation.

The Eneu Island station is about 15 m upwind of a one-story building. The trees are about 30 m upwind of the Eneu station. These trees are not very close together, and the grove has very little underbrush to restrict airflow.


2 Gouveia et al.


Station name	Island	Latitude	Longitude	Upwind distance to waterline (m)	Remarks
Control Plot	Bikini	11°37'44"N	165°32'50"E	500	Small clearing of dense trees
House 36	Bikini	11°37'40"N	165°32'32"E	1000	Broad clearing near lagoon
Eneu Island	Eneu	10°31'29"N	165°33'59"E	200	In large clearing of sparse trees near center of island




0 200 400 890 1200 1600

Figure 1. Map of Bikini Island with the locations of meteorological stations.







Sensors

Each system features sensors for wind, air temperature and humidity, solar radiation, and rain (Table 2). The anemometers are mounted at the top of 10-m towers. The air temperature and humidity sensors are inside naturally aspirated solar shields, and located about 3 m above the ground. The solar sensor is located about 3 m above the ground on a crossarm extending from the tower towards the South. Each station includes two rain gauges. Five of the six rain gauges are within 10 m of their respective tower. The exception is the House 36 station that has a rain gauge on the Excavation Plot as well as near the tower base.

Manual Rain Gauge

A rain gauge near the DOE station on Bikini Island is read every day at 7 pm. The daily total of rain is recorded in a logbook, the information copied and sent onto LLNL.

Data Logger

The wiring diagram appears in Appendix A. The same wiring scheme is used for all three loggers. We are using Campbell Scientific CR10X data loggers.

Appendix B presents the logger programs used for each station. The sensors are polled every ten seconds with averages computed every hour. Additionally, the standard deviation of the wind direction, cumulative rainfall, and daily rainfall are computed and retained. These data are sent to the GOES transmitter. Every three hours, according to the programmed schedule, the data are transmitted to the GOES-W satellite. The loggers have the capacity for over three years of data.

DAPS

The data sent to the GOES satellite are transferred to NOAA's Wallops Command and Data Acquisition Station. The data can be downloaded via their web site (http://dcs.noaa.gov/). Downloading requires first contacting the DAPS / DCS (Data Collection System) staff (Email: daps@wcda.wff.nasa.gov). The IP address of your download computer is needed along with the DAPS account name (LLL18W), and an e-mail address for communication.

The downloaded file should have a file name that identifies the date of the download. For example the file name for data downloaded on April 30, 2001 was B010430.TXT.

Procedures

Development of a detailed operations and training manual for the meteorological stations was beyond the scope of this paper. This section

describes in general terms how to calibrate and install the meteorological sensors, and retrieve data from the systems.

Table 2. List of variables measured at each station and the type of sensors used.

Variable	Sensor type	Model	Remarks
Wind speed	3-cup	Handar 430	Starting threshold ~0.5 m/s
Wind direction	Vane	Handar 431	Starting threshold ~0.5 m/s
Air temperature	Thermistor	Handar 435	YSI 44006 element
Relative humidity	Thin-film capacitor	Handar 435	Vaisala Humicap element
Incoming solar radiation	Silicon photodiode	Licor 200	Measures light level
Rainfall	Tipping bucket	Various	0.01" per tip

Inventory of Sensors

At this time, there are many sensors stored at LLNL and on Bikini Island that can be used in the field. Table 3 is an inventory of the sensors that are part of the Marshall Islands Program. Although most of the individual items in this table are ready for field use, some may require repair, or are beyond repair and should be decommissioned. In time, the unusable sensors will be fixed and stored, or salvaged and taken off the inventory. The temperature sensors listed in Table 3 will be held in reserve, and may be fielded when the relatively fragile, temperature and relative humidity sensors do not perform properly.

Calibration of Sensors

The meteorological sensors are calibrated and checked following the guidelines in EPA (1990). Before installation, each sensor is checked for damage and compared against a standard. If it is within acceptable range of the standard, the sensor is stored ready for use. The usual practice for bench checking a sensor involves a CR10X logger and testing equipment. First, the sensor is cleaned and damaged parts are fixed or replaced.

While in the field, the sensors from the three stations can be compared together. A sensor that is not performing properly will deviate from similar sensors on the other systems. Sometimes short-term deviations can be explained by a small-scale weather disturbance, e.g. rainsqualls.

Wind Speed

After the cups are removed, the wind speed sensor is attached to a tachometer. The shaft is rotated at exact frequencies and the output is compared to the expected speeds. The sensor passes if the speeds are all within $0.2~{\rm m~s^{-1}}$ of the expected values.

The roll test tests the starting torque of the wind speed sensor. With the cups attached, roll the sensor on a flat, level table. If the cups do not rotate while the sensor body is slowly rolled, the sensor passes this simple test. If necessary, the bearings of a wind speed sensor can be replaced to decrease the starting torque.

Wind Direction

The vane of a wind direction sensor can be rotated to several known angles and the output checked. When a 180° screw is installed just below the vane, the output should indicate a south wind (180°). The easiest angles to check are the four cardinal directions: 90°, 180°, 270°, and 0° (or 360°). If any of these angles is off by more than 3 degrees, the sensor should not be used in the field. A torque wheel can also be used to measure the starting torque of the shaft. The starting torque for the Handar 431 wind direction sensor should be less than 6.5 gm cm.

Temperature

A temperature sensor can be compared to an accurate thermometer. If the indicated temperature is 0.5°C from the standard, the sensor should not be used in the field. This check against a standard can be done at just one temperature. Since the expected range of ambient air temperature at Bikini Atoll is very narrow (24 to 34°C) it is not necessary to check the sensor at more than one temperature. The thermistors must not be immersed in water.

Relative Humidity

The relative humidity sensor is the sensor most likely to deviate from its factory calibration. The thin polymer film over the capacitance element is susceptible to contamination. The relative humidity sensor can be compared to a standard sensor or held over salt solutions providing a known humidity. If the sensor is more than 5% from the standard, it should not be used.

Solar

The solar cell can be compared to a recently calibrated pyranometer. A special program has been written for the CR10X to continuously sample the solar cell(s) and the standard(s), and compute 1-minute averages. The sensors are co-located and exposed to several hours of full sunlight. The resulting data can be analyzed to verify the factory calibration or create a new calibration factor. Alternatively, there are several companies that will find the calibration factor of any solar cell. The

Sensor Type	Number	Serial numbers in inventory					
Wind Speed	18	112, 463, 471, 652, 657, 660, 667, 769, 772, 790, 984, 1077, 1096, 1102, 1121, 2254, 2255, 2343					
Wind Direction	18	339, 465, 598, 603, 604, 611, 640, 704, 709, 714, 722, 1048, 1050, 1171, 1809, 2191, 2192, 2233					
Temperature	9	108, 348, 375, 407, 408, 409, 667, 954, 958					
Temperature and Relative humidity	7	652, 655, 662, 672, 2751, 3115, R35857					
Solar	7	0881-7603, PY17830, PY2043-8001, PY33682, PY33683, PY722-7609, PY8129					
Rain gauge	13	WT-2666, WM-3670, WM-3710, WM-2584, 2170, 405, plus 7 with unknown serial numbers					

Table 3. List of sensors used by the Marshall Islands Program. This inventory was taken in May 2001.

individual calibration factor will not be applied in the logger program. Rather, a standard calibration factor will be used in the program. The individual calibration factor will be used when the data is post processed for inclusion in the monthly files.

Rain Gauge

A rain gauge can be calibrated by simply pouring 1-liter of water into its funnel. This operation can be done in the laboratory or in the field. A rain gauge calibration bottle can be used to slowly dribble the water into the rain gauge. One liter of water poured very slowly into the rain gauge will be counted as 1.09 inches of rain. If the indicated rain is less than 0.98" or greater than 1.20" (± 10%) the calibration should be repeated. If a value outside the acceptable range persists, the gauge should be replaced. When calibrating a rain gauge in the field, choose a rainless day. Make a note of the station, date and time of the calibrations, and before and after rainfall readings. Remove the calibration data from the post processed data included in the monthly files.

Installation of Sensors

We have decided to swap sensors only after they exhibit signs of wear or deviation from calibration. The data should be reviewed weekly with emphasis on comparisons between the three stations.

The wind direction sensor is fitted in a sleeve that remains fixed to the crossarm. It is important not to loosen the two Allen screws that hold the sleeve to the crossarm. The sensor is fixed to the sleeve by a single, small, Phillips-head screw.

Before removing the sensor, check the alignment of the vane. Insert in the 180° screw into the hole under the tail of the vane. When properly installed, this screw will force the sensor into the 180° position, which indicates wind from the South. With a magnetic compass, and being mindful of the local declination (about + 8°), check the alignment of the sleeve. Checking the alignment can also be done with a GPS receiver.

If the sleeve position is correct, the new wind direction sensor can be installed in the sleeve. The sensor reading should be 180° when the 180° screw is in place. The crossarm should also be lined up to true North. Check a few other angles after removing the 180° screw and rotating the vane parallel and perpendicular to the crossarm.

The wind speed and temperature sensors do not require alignment. To remove one of these sensors, simply detach the connector and loosen the two Allen screws. Reverse this process to install the fresh sensor.

The solar cell is mounted on its own crossarm. A specialized mounting bracket holds the solar cell. The bracket has a bubble level to aid in leveling the solar cell. First loosen the hold-down screws, and then adjust the leveling screws until the bubble is centered. Finally, tighten the hold-down screws while keeping the bubble level centered. The crossarm is low enough to provide easy access for service by standing on a 6-foot ladder while the tower is in its final, upright position.

Threaded studs projecting from concrete slabs hold the rain gauges. The funnel/hood can be removed to gain access to the electrical terminal and leveling bubble. Most problems with the rain gauges can be traced to debris in the funnel or tipping buckets, and broken or disconnected terminal wires.

Data Recovery

There are two basic ways to retrieve data from the loggers: via-satellite and on-site. Collecting data via satellite is the routine method of data collection. It involves a desktop PC and an Internet connection to the NOAA Wallops Command and Data Acquisition Station. The on-site method requires a direct connection to the logger.

Via Satellite

Currently there are two methods for downloading data from NOAA: telnet and web-based. Both methods require the user name (LLL18W) and a password. The DCS web site, http://dcs.noaa.gov/, has a link for telnet access.

Web-based downloads can be made through the URL http://dcs.noaa.gov/default1.asp.

Data downloaded via satellite includes a DAPS message (Table 4) and the DCP data. A typical data string that represents three hours of data from one logger is 293 bytes long, not including the 37-byte DAPS message.

The downloaded data follows the DAPS download message. The data is coded to reduce size. Each number is coded into three characters. Appendix C includes the FORTRAN source code that converts three characters into the numeric equivalent. For

example, the string @_Q is converted to the value 2001.

On Site

All the data that are in the memory of the logger can be downloaded to a storage module or laptop computer. The 2-Megabyte loggers can hold over three years of data. For this download method, use a keyboard (model CR10KD), and storage module (SM4M) connected with the same blue cable (SC12). Connect the combination to the CS I/O port on the logger. The data on the module is downloaded to a computer running the Windows-based program PC208W. The data file can then be copied to floppy, and sent to LLNL for analysis and archiving.

Monthly Files

Every month, data from all three stations are compiled into a single Excel workbook. The tables and graphs created in these workbooks should be reviewed for completeness, and crosschecked. Appendix D contains a series of plots of the Bikini meteorological data created for each month from May 2000 through February 2001.

Annual Files

Selected data from every month are compiled into an Excel workbook representing a summary of the entire year. A series of tables and charts from the year 2000-2001 is shown in Appendix E. The meteorological year for Bikini coincides with the calendar year.

Summary of 2000-2001 Data

Every year a summary of the experiences with the Bikini meteorological system should be consolidated into a report for distribution within the Marshall Islands Program. Included should be tables of daily and monthly totals of rainfall, reports of missing data, sensor-swap reports, and any other significant data or news pertaining to the system. The following section is a summary report for the period from the installation of the new loggers

Example	Size (bytes)	Name of field	Notes
CA3022A	8	Address of logger	
01	2	Year message was received	01 is 2001
31	3	Day of year message received	131 is 11 May for non-Leap Year
9	2	Hour message was received	GMT
:6	2	Minute message was received	
24	2	Second message was received	
3	1	Status code	G for Good data; ? for parity error
16	2	Signal strength	Between 44 and 48 is normal
4	2	Frequency offset	50 Hz steps; $-4 = -200$ Hz; ± 8 is normal
J	1	Modulation index	N is Normal
V	1	Data quality	N is Normal
030	3	Channel message was received	30 or 28
N	1	GOES Spacecraft	W is GOES West
00	2	Uplink carrier status	00 is normal
00293	5	Length of message in bytes	

Table 4. Interpretation of the DAPS download message string following this example: CA30022A01131094624G46-4NN030W0000293.

and transmitters in early May 2000 through the end of April 2001.

Mission and Station Reports Spring 2000 Mission

By 2 May 2000, three new Campbell Scientific CR10X loggers were installed on Bikini Atoll. The existing sensors and towers were combined with new loggers, satellite transmitters and enclosures. The circuitry was simplified, and the logger programs were standardized among the stations. The only sensors not operating at this time were the solar cells, which lacked precision resistors. All the other sensors were swapped with reconditioned sensors. The rain gauges were all checked with a rain gauge calibrator Spring 2001 Mission

Errors in satellite data transmission and timing problems when downloading caused numerous small gaps in the real-time data recovery. Most of these gaps were recovered by Richard Giles in January 2001 by on-site downloading to a storage module. A manual download was also performed during the spring mission. There was a possible 8544 hours of data collection for the period from 9 May 2000 to 30 April 2001. The proportion of data recovered that produced valid wind speed and direction data was 98.8% for Control Plot, 77.7% for House 36, and 41.7% for Eneu.

New solar sensors, complete with the proper precision resistors, were installed in all three stations. House 36 and Control Plot received new solar

sensors, while the Eneu station received an old, calibrated and accurate sensor. We manufactured new crossarms to hold the solar sensors. The new crossarms are attached to the towers a few feet above the logger enclosure. This low height ensures that there will be no need to extend the signal wire. Also, alignment of the solar sensor can be done while standing on a 6-foot ladder.

House 36

An unexplained change in the House 36 logger program starting on 5 August 2000 and ending on 9 September 2000 resulted in a loss of several data channels. During this 34-day period, most of the parameters were not recovered, although wind speed, hourly rainfall, and box temperature were unaffected. On 9 September the logger was reprogrammed. After this date, all channels were collected properly. Unfortunately, the logger was reset at that time, and it was not possible to perform an on-site recovery of the data taken before 9 September. The on-site recovery procedures done in January and April 2001 filled in all the gaps in the House 36 data to yield a complete set of data after 9 September.

Control Plot

The transmitter on the Control Plot system operated properly from the install date in May 2000 until late in October. The timing and frequency shifted outside the functioning window and data recovery via satellite was interrupted. This transmitter was replaced during the Spring 2001

mission and sent to Campbell Scientific for warranty repairs. The on-site data recovery successfully retrieved all the data starting in May 2000.

The ambient relative humidity data for the Control Plot is obviously shifted in scale, which can be seen when compared to the House 36 data (see Appendix D). The RH sensor was out of calibration from May 2000 until it was replaced on 4 April 2001. It is hoped that the data taken before 4 April can be adjusted with acceptable precision. Figure 3 illustrates one possible method to make this adjustment. The ambient humidity data taken before and after 4 April shows a roughly linear relationship between the Control Plot and House 36 stations. The data taken before the sensor replacement were adjusted by a linear equation to best fit the post-swap data. This adjustment method may not be appropriate since the House 36 humidity sensor has not been proven to be perfectly accurate. We will perform several procedures during the next field mission to calibrate the RH sensors.

Eneu

The base of the Eneu tower was corroded to the point that it was unsafe to climb or tilt the tower to swap the anemometer set. After the Spring 2000 mission, Wayne Olival and his support crew replaced the base. We were able to tilt the tower during the Spring 2001 mission and replace all sensors except the rain gauges.

The Eneu logger inexplicably stopped data transmission via satellite on 29 November 2000. The attempt to recover the lost data with an on-site download was unsuccessful in January 2001. While servicing the Eneu system during the spring mission, we found that the logger program was incorrect and actually set to sit idle. These problems were corrected on 3 April 2001 and the Eneu station is currently working properly.

Historical Rainfall Data

The Marshall Islands Program has maintained several rain gauges on Bikini Island since July 1985.

The longest and most-complete record comes from the manual gauge located near the Department of Energy (DOE) compound. This gauge is a simple graduated rain collector. Every day at 7 p.m. the gauge is read, and the total daily rain is recorded in a notebook. The rain record from this gauge is complete except for a few missing days in April, May, and July of 1992.

In April 1990, five gauges were installed as part of the automatic weather-monitoring system on Bikini Atoll. Two gauges were part of the Control Plot system, two at House 36, and one on Eneu with a second installed in May 2000.

Monthly totals of rain measured by all six Bikini Atoll rain gauges are listed in Appendix F. The monthly totals are computed from daily values. Data are omitted from the monthly list when there are significant missing daily data. The column on the far right (Bikini Isle average) represents the best estimate for the monthly rainfall for Bikini Island. This column is computed from all valid data from the Bikini Island gauges (Control Plot, House 36, and the Manual gauge). Before May 2000 the Bikini Isle average was computed using monthly data. From May 2000 to present daily totals are used to compute the Bikini Isle average.

The annual summary of the monthly rain data from Appendix F appears in Table 5. The average rainfall computed from the 13 years of Bikini Isle averages (1986 through 1998) is 64.8" (164.6 cm). The column in Table 5 of Bikini Isle averages is presented in Figure 4. The asterisks above the bars for the years 1985, 1999, and 2000 indicate that the totals for these years are incomplete.

The average monthly rainfall illustrated in Figure 5 is based on the Bikini Island averages in Appendix F. Table 6 shows the monthly averages for all the rain gauges on Bikini Atoll. Differences among these monthly averages are caused, in large part, by the mixture of months that make up the individual average. The annual average computed from the




Figure 3. Comparison of relative humidity as measured at the Control Plot and House 36 stations. Least-squares fits are included for the original CP data taken before the sensor swap on 4/4/01, the CP data after the swap, and the adjusted CP data

Table 5. Historical values of the annual total rain (inches) for the Bikini Atoll gauges. Based on all available data from July 1985 through April 2001.

Year	CP1	CP 2	H36 1	H36 2	Eneu 1	Eneu 2	Manual gage	Bikini Isle average
1985	33.66a	n/a	n/a	n/a	n/a	n/a	33.50 ^a	33.58 ^a
1986	15.14 ^a	n/a	n/a	n/a	n/a	n/a	82.05	79.32
1987	n/a	n/a	n/a	n/a	n/a	n/a	44.98	44.98
1988	n/a	n/a	n/a	n/a	n/a	n/a	50.84	50.84
1989	n/a	n/a	n/a	n/a	n/a	n/a	71.87	71.87
1990	40.46 ^a	44.47^{a}	76.82 ^a	81.89 ^a	88.40	n/a	104.25	98.09
1991	57.97 ^a	58.80	2.84^{a}	71.18	56.12	n/a	73.98	68.77
1992	54.77	37.31 ^a	36.81 ^a	43.31 ^a	53.64	n/a	59.37 ^a	56.62
1993	39.39 ^a	22.87 ^a	28.63 ^a	28.97 ^a	36.54 ^a	n/a	61.11	60.78
1994	10.01 ^a	8.62 ^a	40.91 ^a	45.56 ^a	23.43 ^a	n/a	68.42	63.67
1995	52.44	40.68 ^a	51.37 ^a	52.32	12.82 ^a	n/a	57.78	52.55
1996	41.79 ^a	34.50 ^a	38.43 ^a	42.33a	n/a	n/a	73.52	65.99
1997	87.29	73.32	68.11 ^a	91.02 ^a	n/a	n/a	n/a	84.88
1998	2.11 ^a	1.86 ^a	1.31 ^a	1.75 ^a	n/a	n/a	43.74	42.62
1999	n/a	n/a	n/a	n/a	n/a	n/a	31.26	39.47
2000	43.67 ^a	42.47 ^a	35.45 ^a	33.77 ^a	25.73 ^a	26.62 ^a	51.92	43.83

^a Incomplete data.




Figure 4. Annual total rainfall for the year 1985 through 2000 from the Bikini Island average.




Figure 5. Monthly average of rain based on the best estimate of all Bikini Island data.

Month	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gauge	Bikini Isle average
Jan	1.67	1.22	1.29	1.51	1.74	n/a	1.92	1.70
Feb	1.11	1.17	1.26	1.09	1.00	n/a	1.47	1.37
Mar	2.76	2.43	3.06	2.56	3.05	n/a	2.33	2.66
Apr	2.45	2.35	2.74	2.77	1.86	0.18	2.27	2.30
May	3.29	2.31	2.48	3.18	2.38	1.19	2.81	2.88
Jun	3.17	3.04	4.16	4.29	3.34	0.86	5.13	4.86
Jul	6.52	6.23	6.45	6.10	5.89	6.52	7.39	6.70
Aug	9.30	8.99	8.32	9.42	7.56	9.45	7.89	8.05
Sep	9.26	8.60	9.39	10.08	7.79	3.08	9.25	9.61
Oct	9.38	8.99	8.10	9.15	7.40	5.52	8.95	8.34
Nov	8.20	7.13	8.85	7.91	9.21	n/a	9.50	8.74
Dec	2.71	3.03	3.36	3.47	3.82	n/a	3.78	3.57
Annual	59.8	55.5	59.5	61.5	55.0	n/a	62.7	60.8
Relative to Bikini Island average	-2%	-9%	-2%	1%	-9%	n/a	3%	

Table 6. Historical values of monthly average rain (inches) for the Bikini Atoll gauges. Based on all available data from July 1985 through April 2001.

Bikini Island average is 61.1" (155.2 cm). More data will improve the meaning of these statistics. For instance, the large average from the West gauge on Eneu for the month of November (12.48") is based on just three years of data, 1989-1991. The month of November during those three years featured especially high rainfall.

The data in the line of annual averages in Table 6 are computed from a set of months with complete data from all the Bikini Island gauges: Control Plot, House 36, and the Manual gauge. The last line in Table 6 is the relative difference between the station estimate of annual total rainfall and the Bikini Island annual average. The relative differences may indicate instrument error or a geographic difference in rainfall as measured by the rain gauge stations. The North gauge at the Control Plot station shows a persistent relative deficit of rain. This pattern can also be seen in the monthly traces of cumulative rainfall in Appendix D. It is possible that this gauge was placed in a location that is in the rain shadow of some nearby trees. The Tower gauge on the House 36 station and the Manual gauge consistently have the largest rainfall amounts. There may be a slight gradient of precipitation across Bikini Island with larger amounts of rainfall closer to the lagoon.

Rainfall Since May 2000

A detailed diagram of cumulative rainfall as measured by the 6 rain gauges is presented in Figure 6. All six traces track each other very well. An exceptional rainfall event occurred in late November 2000 when almost 12" of rain fell in a 10-day period. The largest single day rainfall occurred on 8 July 2000 when about 5" was measured by the Bikini Island gauges. Although the Eneu gauge detected just 3.5" at that time, a rainfall event on 6 August of about 4.4" brought the Eneu seasonal total close to the Bikini Island values. The average total rainfall for all 6 gauges was 47.5" during this 360-day period. Despite differences in locations, exposures, instrument bias, and rough adjustments, 4 of the 6 gauges were within 1% of this average.

The rainfall record from the Control Plot station is complete during the period in Figure 6. The total rainfall as measured by the two Control Plot gauges was 48.62 and 47.30", respectively. The small difference of just 2.8% is within the accuracy specifications especially when we consider that some of this difference may come from a variation in exposure.

The House 36 data recovery was intermittent from 5 August through 10 September 2000.




Figure 6. Cumulative daily values of rainfall for the 6 rain gauges on Bikini Atoll for the period starting 6 May 2000 through 30 April 2001.

The missing cumulative rainfall channels complicate this problem. The House 36 data is complete after 10 September. We added 7.5" to the data from both House 36 gauges to bring the total rainfall close to the Control Plot values. We believe this is a reasonable estimate for rainfall through the gap in data.

The Eneu data was interrupted from 29 November 2000 to 4 April 2001. It is estimated that 12" of rain fell on Eneu Island during the extended period of missing data. Before this period, the Eneu data features small gaps caused by errors in satellite transmission. The small gaps do not affect the accuracy of the cumulative rainfall data, and the daily total rainfall can be reasonably reconstructed from these data.

Wind Speed

Although the size of the data sets from the three stations is different, the frequency of wind speed computed from all available data (Figure 7) shows a persistent pattern. See also monthly wind speed plots

in Appendix D. The typical pattern reflects the density of the trees and the proximity of trees to the station. The lowest wind speed is typically from the Control Plot's station, the highest from House 36. For instance, 26% of the Control Plot winds are class 2 and less (WS<3 ms⁻¹), Eneu is 40%, and House 36 is 70%. The cumulative frequencies of wind speed are also at the bottom of the three tables in Appendix G.

Monthly Average Wind Speed

Using all available data, the average wind speed was computed for every month from May 2000 to April 2001. The time series of the monthly averages (Figure 8) reflects the differences in exposure among the 3 sites. The Control Plot speeds are, on average, 1 ms⁻¹ less than the House 36 and Eneu speeds.

Monthly Average Air Temperature

The monthly average air temperatures (Figure 9) show a slight, but definite, seasonal variation. The averages were computed from all available




Figure 7. Histogram of cumulative frequency of wind speed class using all available data from May 2000 through April 2001. The classes are determined by removing the fractional portion of the wind speed (i.e., WS=1.5, Class=1).




Figure 8. The monthly average wind speed from three Bikini Atoll stations.




Figure 9. The monthly average air temperature from three Bikini Atoll stations, and the monthly maximum and minimum temperature from the Control Plot station.

hourly data. Again, the most complete data set comes from the Control Plot station so it should be viewed as the most reliable representation of air temperature. Some of the variation in the temperature from the other stations comes from the small differences in ventilation, instrument error, or incompleteness in the data set. For example, the Eneu station data set for the months of September, October, and November, in particular, have a large number of missing values.

The range of temperatures also shows a slight but detectable seasonal pattern. The difference between highest and lowest temperatures was 12°C in late summer and less than 8°C in the winter. This small amplitude cycle may be caused by the seasonal change in rainfall, cloud cover, or wind speed.

The slight decrease in speed during the summer may cause less vertical mixing, an increase in temperature at the inside the solar shield, and larger diurnal change of temperature.

Annual Windrose

A complete set of wind rose tables and diagrams appear in Appendix G. The roses show differences between the Control Plot and House 36 wind directions that were caused by instrument error in the House 36 wind direction sensor, and possibly slight misalignment at one or both sites. The Eneu windroses feature winds that are rotated towards north compared with Bikini Island stations.

Summary

This document describes in general terms the monitoring systems that collect meteorological data on Bikini Atoll. Included is a complete set of monthly time series of selected hourly data from the three current stations. Tables of daily rainfall from 14 May

2000 to present are included as well as historical totals of monthly rainfall.

This document is the first of a series of annual reports of the Marshall Islands meteorological systems. Future reports will describe significant changes in instrumentation and procedures.

Acknowledgment

The continuing scientific program on Bikini Atoll is made possible through the efforts of Lance Yamaguchi and his staff from Bechtel Nevada who provide all the logistics support for the program. We would especially like to thank Kenny Selk, Richard Giles, Wayne Olival, Jaspar

Riklon, and Mat Aiseia for helping construct and maintain the meteorological stations. This work was performed under the auspices of the U. S. Department of Energy by the University of California, Lawrence Livermore National Laboratory under Contract No. W-7405-Eng-48.

References

EPA (1990), Quality Assurance Handbook for Air Pollution Measurement Systems, Volume IV—Meteorological Measurements, EPA-600/4-90/003, U.S. Environmental Protection Agency, Office of Research and Development, Research Triangle Park, NC.

Appendix A

Wiring Diagrams

Anemometer crossarm cable

Sensor	540 connector		Function	CR10X
WD A	brown	В	+1 v reference	E3
WD B	black	D	Signal ground	G
WD C	red	С	WD signal	SE6
WS D	blue	Е	+12 v supply	12V
WS E	black	D	Signal ground	G
WS F	white	F	WS Pulses	
				20 kΩ

T/RH cable

Sensor	540 connector		Function	CR10X
<u>A</u>	white	F	+12 v supply	12V
В	green	D	Signal ground	G
C	blue	ue E RH signal		SE4
D	brown	A	T signal	SE3
E	red	В	T supply	E2
			Precision bridge	
				1 kΩ 1%


Rain gauge cable

Sensor	Function	CR10X
A	+5 v supply	5V
В	Signal	P6 or P7

Note 1: The terminals on the rain gauge are unmarked.

Note 2: Use P6 for gauge #1, P7 for gauge #2.

Solar cell cable



Appendix B

Logger Programs

Eneu B-2

House 36 B-5

Control Plot B-8

Program for Eneu

```
; {CR10X}
                                                 ;----- Vane
; All current sensors: WD, WS, Rain, T/RH, Solar
                                                 ; Read Vane
; Program for Eneu
                                                 11: Excite-Delay (SE) (P4)
; 8 Apr 2001 Frank Gouveia
                                                 1: 1
                                                             Reps
                                                 2: 15
                                                             2500 mV Fast Range
*Table 1 Program
                                                 3: 6
                                                             SE Channel
                                                 4: 3
5: 2
 01: 10 Execution Interval (seconds)
                                                             Excite all reps w/Exchan 3
                                                         Excite all lord Delay (units 0.01 sec)
1: If Flag/Port (P91)
                                                 6: 1000
                                                          mV Excitation
1: 21 Do if Flag 1 is Low
                                                 7: 6
                                                            Loc [ WD
2: 30
                                                 8: .360
                                                             Mult
           Then Do
                                                 9: 0.0
                                                            Offset
    2: Do (P86)
     1: 11 Set Flag 1 High
                                                 ;----- Cups
                                                 ; Read Cups
    3: Automatic Setup of TGT1 (P123)
                                                 12: Pulse (P3)
                                                 1: 1
     1: 12
           Address
                                                             Reps
     2: 10
                                                 2: 1
             Address
                                                             Pulse Input Channel
                                                 3: 3
     3: 3
             Address
                                                             High Frequency, 16 Bit, All
     4: 1
             Address
                                                  4: 7
                                                            Loc [ WS
                                                                           ]
     5: 1
                                                  5: .159744 Mult
             Address
     6: 3
             Address
                                                  6: 0
                                                            Offset
     7: 10
             Address
                                                 ;----- Rain
     8: 6
             Address
     9: 28
             Assigned Uplink Channel
                                                 ; Read CP6 for rain gauge, 0.01" per tip
    10: 0
             Random Uplink Channel
                                                13: Pulse (P3)
                                                         Reps
    11: 0
             Self-timed Interval Days
                                                1: 1
2: 6
    12: 3
             Self-timed Interval Hours
                                                             Pulse Input Channel
                                                3: 2
4: 8
    13: 0
             Self-timed Interval Minutes
                                                             Switch Closure, All Counts
    14: 0
             Self-timed Interval Seconds
                                                             Loc [ Rain1_inc ]
    15: 0
            Random Interval Hours
                                                5: .01
                                                            Mult
    16: 0
             Random Interval Minutes
                                                 6: 0
                                                             Offset
    17: 0
             Random Interval Seconds
    18: 1
             Initial Self-timed Hours
                                                ; Add reading to total
    19: 50
             Initial Self-timed Minutes
                                                14: Z=X+Y (P33)
             Initial Self-timed Seconds
                                                 1: 8
                                                            X Loc [ Rain1_inc ]
    20: 0
                                                 2: 10
             One Minute Window
                                                            Y Loc [ Rain1 ]
    21: 0
    22: 0
             Short Preamble
                                                 3: 10
                                                            Z Loc [ Rain1
    23: 1
             Self-Timed Buffer
                                                 ; Read CP7 for rain gauge, 0.01" per tip
; Identifier for Eneu is 31
                                                15: Pulse (P3)
    4: Z=F (P30)
                                                 1: 1
                                                             Reps
     1: 31
                                                  2: 7
                                                             Control Port 7
                Exponent of 10
                                                 3: 2
                                                             Switch Closure, All Counts
     2: 0
     3: 1
               Z Loc [ Station]
                                                             Loc [ Rain2_inc ]
                                                 4: 9
                                                 5: .01
                                                            Mullt
    5: Z=X+F (P34)
                                                 6: 0.0
                                                             Offset
              X Loc [ Station
     2: 0.11
                F
                                                 ; Add reading to total
     3: 19
               Z Loc [ WindID
                                                 16: Z=X+Y (P33)
                                                 1: 9
                                                            X Loc [ Rain2_inc ]
                                                            Y Loc [ Rain2 ]
    6: Z=X+F (P34)
                                                 2: 11
     1: 1
              X Loc [ Station ]
                                                 3: 11
                                                            Z Loc [ Rain2
     2: 0.15
               F
                                                 ;----- RH
     3: 20
               Z Loc [ RainID ]
                                                 ; Read the RH voltage (0-1v = 0-100%)
    7: Z=X+F (P34)
                                                 17: Volt (SE) (P1)
     1: 1
                                                 1: 1 Reps
             X Loc [ Station ]
     2: 0.05
                                                 2: 5
                                                             2500 mV Slow Range
              Z Loc [ DRainID ]
                                                 3: 4
                                                             SE Channel
     3: 21
                                                  4: 13
                                                             Loc [ RH
8: Z=X+F (P34)
                                                 5: 0.1
                                                             Mult
              X Loc [ Station ]
     1: 1
                                                 6: 0
                                                            Offset
     2: 0.16
               F
     3: 22
              Z Loc [ TempID ]
                                                 ;----- Temperature
                                                 ; Read the thermistor
    9: Z=X+F (P34)
                                                 18: Excite-Delay (SE) (P4)
                                                 1: 1 Reps
     1: 1
              X Loc [ Station ]
     2: 0.01
                                                 2: 4
                                                             250 mV Slow Range
               F
                                                           SE Channel
     3: 18
              Z Loc [ BoxID ]
                                                 3: 3
                                                 4: 2 Excite all reps w/Excha
5: 0 Delay (units 0.01 sec)
                                                            Excite all reps w/Exchan 2
10: End (P95)
                                                  6: 1000 mV Excitation
```

```
7: 12
           Loc [ Tmister ]
                                                   1: 2
                                                            Reps
8: .004
           Mult
                                                   2: 10
                                                              Loc [ Rain1
9: 0.0
           Offset
                                                  ;---- Output daily total of Rain
; Convert 0.004 mv to Celsius
                                                  ; Every day write daily total of rain
19: Polynomial (P55)
                                                  32: If time is (P92)
                                                            Minutes (Seconds --) into a
1: 1
         Reps
                                                   1: 1140
2: 12
                                                  2: 1440
           X Loc [ Tmister ]
                                                              Interval (same units as above)
3: 14
           F(X) Loc [ T_C
                                                  3: 10
                                                            Set Output Flag High (Flag 0)
4: -37.557 CO
5: 430.8
                                                  33: Set Active Storage Area (P80)
6: -1441.7 C2
                                                   1: 1 Final Storage Area 1
7: 2938.8 C3
                                                   2: 5
                                                              Array ID
8: -3010.4 C4
9: 1200.2 C5
                                                  34: Real Time (P77)
                                                  1: 1110
                                                             Year, Day, Hour/Minute
;----- Solar
20: Volt (SE) (P1)
                                                  35: Sample (P70)
                                                  1: 1 Reps
2: 21 Loc [ DRainID ]
1: 1 Reps
           25 mV Slow Range
2: 3
2: 3 25 mV Slow Range
3: 7 SE Channel
4: 15 Loc [ Solar ]
5: 100 Mult
6: 0 Offset
                                                  36: Totalize (P72)
                                                  1: 2 Reps
                                                   2: 8
                                                              Loc [ Rain1_inc ]
                                                  ;----- Output T, Solar
;----- Output Wind
                                                  ; Every hour write array 16, T, Solar
; Every hour write array 11, WS & WD
                                                  37: If time is (P92)
                                                  1: 0 Minutes (Seconds --) into a
2: 60 Interval (same units as above)
3: 10 Set Output Flag High (Flag 0)
21: If time is (P92)
1: 0 Minutes (Seconds --) into a
2: 60
           Interval (same units as above)
       Set Output Flag High
3: 10
                                                  38: Set Active Storage Area (P80)
                                                   1: 1 Final Storage Area 1
2: 16 Array ID
22: Set Active Storage Area (P80)
1: 1 Final Storage Area 1
                                                  2: 16
2: 11
           Array ID
                                                  39: Real Time (P77)
23: Real Time (P77)
                                                  1: 1110 Year, Day, Hour/Minute
1: 1110
           Year,Day,Hour/Minute
                                                  40: Sample (P70)
                                                  1: 1 Reps
2: 22 Loc [ TempID
24: Sample (P70)
      Reps
Loc [ WindID ]
1: 1
2: 19
                                                  ; Average RH, T, Solar
; Write Avg WS, Avg WD, Sigma Theta
                                                  41: Average (P71)
                                                  1: 3 Reps
25: Wind Vector (P69)
1: 1 Reps
2: 0 Samples per Sub-Interval
3: 00 Sensor/Output Option
                                                  2: 13
                                                             Loc [ RH
3: 00 Sensor/Output Option
4: 7 Wind Speed/East Loc [ WS ]
5: 6 Wind Direction/North Loc [ WD ]
                                                  *Table 2 Program
                                                  02: 60 Execution Interval (seconds)
;----- Output 1-hr Rain
                                                  ; Every minute
; Every hour write array 15 with Rain1
26: If time is (P92)
                                                  ;----- Signature
       Minutes (Seconds --) into a
1: 0
                                                  ; Read the program signature
2: 60
           Interval (same units as above)
                                                  1: Signature (P19)
3: 10 Set Output Flag High (Flag 0)
                                                  1: 2 Loc [ Sig
                                                  ;----- Battery
27: Set Active Storage Area (P80)
1: 1 Final Storage Area 1
                                                  ; Read the battery voltage
2: 15
           Array ID
                                                  2: Batt Voltage (P10)
                                                  1: 3 Loc [ Batt
28: Real Time (P77)
         Year,Day,Hour/Minute
                                                  ;----- Box T
1: 1110
                                                  ; Read internal thermistor
29: Sample (P70)
                                                  3: Internal Temperature (P17)
1: 1 Reps
                                                  1: 4 Loc [ Int_T
2: 20
           Loc [ RainID ]
                                                  ;----- Box RH
; Write hour increment of rain
                                                  4: Volt (SE) (P1)
                                                  1: 1 Reps
2: 5 2500 mV Slow Range
30: Totalize (P72)
1: 2 Reps
                                                  3: 12 SE Channel
4: 5 Loc [ Int_RH
5: 0.1 Mult
6: 0.0 Offset
           Loc [ Rain1_inc ]
; Write out seasonal rain amount
                                                             Offset
31: Sample (P70)
                                                   6: 0.0
```

```
;----- - Output Sig, AntPower, Batt, T, RH
                                                  ; Minimum of Battery voltage
; Every hour write the Box variables
                                                  11: Minimum (P74)
                                                  1: 1 Reps
2: 0 Value Only
3: 3 Loc [ Batt
5: If time is (P92)
1: 0000 Minutes (Seconds --) into a
2: 60 Interval (same units as above)
        Set Output Flag High
3: 10
                                                  ; Average Internal T and RH
6: Set Active Storage Area (P80)
                                                  12: Average (P71)
                                                   1: 2
1: 1 Final Storage Area 1
                                                             Reps
2: 1
           Array ID
                                                   2: 4
                                                              Loc [ Int_T ]
7: Real Time (P77)
                                                   ;----- Send data to TGT1
                                                  13: If time is (P92)
1: 1110
           Year,Day,Hour/Minute
                                                   1: 0 Minutes (Seconds --) into a
8: Sample (P70)
                                                    2: 60
                                                               Interval (same units as above)
                                                   3: 30
                                                              Then Do
          Reps
          Loc [ BoxID ]
2: 18
                                                  14: Data Transfer to TGT1 (P120)
; Output Program signature
                                                   1: 000 Binary/Self-Timed/Append
9: Sample (P70)
                                                   2: 16
                                                             FWD/Ref Power Loc [ FwdPwr
1: 1
          Reps
2: 2
          Loc [ Sig
                         ]
                                                  15: End (P95)
; Output Antenna Power
                                                   ;----- Send data to SM716
10: Sample (P70)
                                                   16: Serial Out (P96)
1: 2 Reps
2: 16 Loc [ FwdPwr
                                                   1: 71
                                                              SM192/SM716/CSM1
                        ]
                                                   *Table 3 Subroutines
                                                   End Program
```

Program for House 36

```
; {CR10X}
                                                 10: End (P95)
; Sensors: WD, WS, 2 Rain, T/RH, Solar
                                                 ;----- Vane
; Program for House 36
; 7 Apr 2000 Frank Gouveia
                                                 ; Read Vane
                                                 11: Excite-Delay (SE) (P4)
*Table 1 Program
                                                  1: 1
                                                            Reps
 01: 10 Execution Interval (seconds)
                                                  2: 15
                                                             2500 mV Fast Range
                                                  3: 6
4: 3
                                                            SE Channel
                                                          SE Channe:
Excite all reps w/Exchan 3
1: If Flag/Port (P91)
                                                  6: 1000
7: 6
1: 21 Do if Flag 1 is Low
                                                            Delay (units 0.01 sec)
2: 30
           Then Do
                                                             mV Excitation
                                                  7: 6
                                                            Loc [ WD
    2: Do (P86)
1: 11
                                                  8: .360
                                                            Mult
           Set Flag 1 High
                                                  9: 0.0
                                                            Offset
    3: Automatic Setup of TGT1 (P123)
                                                 ;----- Cups
     1: 12
            Address
                                                 ; Read Cups
     2: 10
                                                 12: Pulse (P3)
               Address
                                                  1: 1
     3: 3
               Address
                                                             Reps
     4: 1
               Address
                                                  2: 1
                                                             Pulse Input Channel
                                                  3: 3
     5: 0
               Address
                                                             High Frequency, 16 Bit, All
     6: 0
                                                  4: 7
               Address
                                                            Loc [ WS
                                                  5: .159744 Mult
     7: 13
               Address
                                                  6: 0
     8: 0
               Address
                                                            Offset
              Assigned Uplink Channel
     9: 28
    10: 0
               Random Uplink Channel
                                                 ;----- Rain
    11: 0
               Self-timed Interval Days
                                                 ; Read CP6 for rain gauge, 0.01" per tip
    12: 3
               Self-timed Interval Hours
                                                 13: Pulse (P3)
            Self-timed Interval .....
Self-timed Interval Seconds
                                                 1: 1 Reps
2: 6 Pulse Input Channel
    13: 0
    14: 0
              Random Interval Hours
                                                             Switch Closure, All Counts
    15: 0
                                                  3: 2
    16: 0
               Random Interval Minutes
                                                  4: 8
                                                            Loc [ Rain1_inc ]
               Random Interval Seconds
    17: 0
                                                 5: .01
                                                            Mult
    18: 0
                Initial Self-timed Hours
                                                  6: 0
                                                             Offset
    19: 28
              Initial Self-timed Minutes
              Initial Self-timed Seconds
    20: 0
                                                 ; Add reading to total
    21: 0
               One Minute Window
                                                 14: Z=X+Y (P33)
                                                 22: 0
               Short Preamble
    23: 1
               Self-Timed Buffer
                                                  3: 10
                                                           Z Loc [ Rain1
; Identifier for House 36 is 36
    4: Z=F (P30)
                                                 ; Read CP7 for rain gauge, 0.01" per tip
     1: 36
                                                 15: Pulse (P3)
     2: 0
               Exponent of 10
                                                  1: 1
                                                            Reps
                                                  2: 7
     3: 1
              Z Loc [ Station ]
                                                             Control Port 7
                                                  3: 2
                                                             Switch Closure, All Counts
    5: Z=X+F (P34)
                                                  4: 9
                                                            Loc [ Rain2_inc ]
                                                  5: .01
     1: 1 X Loc [ Station ]
                                                             Mult.
     2: 0.11
               F
                                                             Offset
     3: 19
              Z Loc [ WindID ]
                                                 ; Add reading to total
    6: Z=X+F (P34)
                                                 16: Z=X+Y (P33)
                                                 1: 9 X Loc [ Rain2_inc ]
     1: 1 X Loc [ Station ]
                                                            Y Loc [ Rain2 ]
     2: 0.15
              F
                                                  2: 11
     3: 20
                                                  3: 11
                                                            Z Loc [ Rain2
              Z Loc [ RainID ]
    7: Z=X+F (P34)
     1: 1 X Loc [ Station ]
                                                 ; Read the RH voltage (0-1v = 0-100\%)
     2: 0.05
              F
                                                 17: Volt (SE) (P1)
                                                  1: 1
     3: 21
             Z Loc [ DRainID ]
                                                            Reps
                                                  2: 5
                                                             2500 mV Slow Range
    8: Z=X+F (P34)
                                                             SE Channel
                                                  3: 4
     1: 1 X Loc [ Station ]
                                                  4: 13
                                                            Loc [ RH
     2: 0.16
              F
                                                  5: 0.1
                                                            Mult.
     3: 22
              Z Loc [ TempID ]
                                                  6: 0
                                                             Offset
                                                 ;---- Temperature
    9: Z=X+F (P34)
     1: 1 X Loc [ Station ]
                                                 ; Read the thermistor
     2: 0.01
                                                 18: Excite-Delay (SE) (P4)
              F
     3: 18
              Z Loc [ BoxID
                                                 1: 1 Reps
                                                            250 mV Slow Range
```

```
3: 3
            SE Channel
                                                     2: 8
                                                               Loc [ Rainl_inc ]
            Excite all reps w/Exchan 2
5: 0
            Delay (units 0.01 sec)
                                                    ; Write seasonal rain
6: 1000
            mV Excitation
Loc [ Tmister ]
                                                    31: Sample (P70)
1: 2 Reps
7: 12
                                                                 Reps
8: .004
            Mult.
                                                     2: 10
                                                                 Loc [ Rain1
9: 0.0
            Offset
                                                    ;---- - Output daily total of Rain
; Convert 0.004 mv to Celsius
                                                    ; Every day write array 5 with daily rain
19: Polynomial (P55)
                                                    32: If time is (P92)
1: 1
         Reps
                                                     1: 1140 Minutes (Seconds --) into a
                                                     2: 1440 Interval (same unico a. 2: 10 Set Output Flag High (Flag 0)
           X Loc [ Tmister ]
F(X) Loc [ T_C ]
2: 12
                                                                 Interval (same units as above)
3: 14
 4: -37.557 CO
5: 430.8
                                                    33: Set Active Storage Area (P80)
6: -1441.7 C2
                                                     1: 1 Final Storage Area 1
7: 2938.8 C3
8: -3010.4 C4
                                                     2: 5
                                                                 Array ID
9: 1200.2 C5
                                                    34: Real Time (P77)
                                                     1: 1110 Year, Day, Hour/Minute
;----- Solar
20: Volt (SE) (P1)
                                                    35: Sample (P70)
1: 1 Reps
2: 3 25 mV Slow Range
                                                     1: 1
                                                                 Reps
3: 7 SE Channel
4: 15 Loc [ Solar
5: 100 Mult
6: 0
                                                     2: 21
                                                                 Loc [ DRainID ]
                                                    36: Totalize (P72)
                                                     1: 2 Reps
           Offset
                                                     2: 8
                                                                 Loc [ Rain1_inc ]
                                                    ;----- Output RH, T, Solar
;----- Output Wind
                                                    ; Every hour write array 16, T/RH
; Every hour write array 11, WS & WD \,
21: If time is (P92)
                                                    37: If time is (P92)
                                                     1: 0 Minutes (Seconds --) into a
2: 60 Interval (same units as above)
3: 10 Set Output Flag High (Flag 0)
       Minutes (Seconds --) into a Interval (same units as above)
1: 0
2: 60
3: 10 Set Output Flag High
22: Set Active Storage Area (P80)
                                                    38: Set Active Storage Area (P80)
      Final Storage Area 1
                                                     1: 1 Final Storage Area 1
2: 11
           Array ID
                                                     2: 16
                                                                Array ID
23: Real Time (P77)
                                                    39: Real Time (P77)
1: 1110 Year, Day, Hour/Minute
                                                     1: 1110 Year, Day, Hour/Minute
24: Sample (P70)
                                                    40: Sample (P70)
1: 1 Reps
                                                     1: 1 Reps
           Loc [ WindID ]
2: 19
                                                     2: 22
                                                                 Loc [ TempID
; Write Avg WS, Avg WD, Sigma Theta
                                                    ; Average RH, T, Solar
25: Wind Vector (P69)
                                                    41: Average (P71)
1: 1 Reps
2: 0 Samples per Sub-Interval
3: 00 Sensor/Output Option
4: 7 Wind Speed/East Loc [ WS
                                                     1: 3 Reps
                                                     2: 13
                                                                Loc [ RH
4: 7 Wind Speed/East Loc | WD | 5: 6 Wind Direction/North Loc [ WD ]
                                                    *Table 2 Program
;----- Output 1-hr Rain
                                                     02: 60 Execution Interval (seconds)
; Write array 15 with Rain1 & Rain2
                                                    ; Every minute
26: If time is (P92)
       Minutes (Seconds --) into a
                                                    ;----- Signature
1: 0
2: 60
            Interval (same units as above)
                                                    ; Read the program signature
3: 10
           Set Output Flag High (Flag 0)
                                                    1: Signature (P19)
                                                     1: 2 Loc [ Sig
27: Set Active Storage Area (P80)
        Final Storage Area 1
                                                    ;-- ----- Battery
1: 1
2: 15
                                                    ; Read the battery voltage
           Array ID
                                                    2: Batt Voltage (P10)
28: Real Time (P77)
                                                     1: 3 Loc [ Batt
1: 1110 Year, Day, Hour/Minute
                                                    :----- Box T
29: Sample (P70)
                                                    ; Read internal thermistor
1: 1
                                                    3: Internal Temperature (P17)
           Reps
           Loc [ RainID
                                                    1: 4 Loc [ Int_T
2: 20
; Write hour increment of rain
                                                    ;----- Box RH
                                                    4: Volt (SE) (P1)
30: Totalize (P72)
         Reps
                                                     1: 1
1: 2
                                                                Reps
```

```
2: 5
           2500 mV Slow Range
                                              ; Minimum of Battery voltage
3: 12
           SE Channel
                                              11: Minimum (P74)
4: 5
          Loc [ Int_RH ]
                                               1: 1 Reps
                                                         Value Only
5: 0.1
          Mult
                                               2: 0
                                                        Loc [ Batt
6: 0.0
          Offset
                                               3: 3
;----- Output Sig, AntPower, Batt, T, RH
                                              ; Average Internal T and RH
                                              12: Average (P71)
; Every hour write the Box variables
                                               1: 2
5: If time is (P92)
                                                         Reps
2: 4
                                                         Loc [ Int_T ]
        Set Output Flag High
                                              ;----- Send data to TGT1
                                              13: If time is (P92)
                                                     Minutes (Seconds --) into a
6: Set Active Storage Area (P80)
                                              1: 0
1: 1 Final Storage Area 1
                                               2: 60
                                                         Interval (same units as above)
2: 1
                                               3: 30
          Array ID
                                                         Then Do
7: Real Time (P77)
                                              14: Data Transfer to TGT1 (P120)
1: 1110 Year, Day, Hour/Minute
                                               1: 000 Binary/Self-Timed/Append
                                               2: 16
                                                         FWD/Ref Power Loc [ FwdPwr ]
8: Sample (P70)
1: 1
         Reps
                                              15: End (P95)
2: 18
          Loc [ BoxID
                                              ;----- Send data to SM716
                                              16: Serial Out (P96)
; Output Program signature
9: Sample (P70)
                                               1: 71 SM192/SM716/CSM1
1: 1
         Reps
2: 2
          Loc [ Sig
                                              *Table 3 Subroutines
; Output Antenna Power
                                              End Program
10: Sample (P70)
1: 2
      Reps
2: 16
          Loc [ FwdPwr ]
```

Program for Control Plot

```
; {CR10X}
                                                  10: End (P95)
; All sensors: WD, WS, 2 Rain, T/RH, Solar
; Program for Control Plot
                                                   ; Read Vane
; 3 Apr 2001 Frank Gouveia
                                                  11: Excite-Delay (SE) (P4)
*Table 1 Program
                                                   1: 1
                                                              Reps
                                                              2500 mV Fast Range
            Execution Interval (seconds)
                                                   2: 15
 01: 10
                                                            SE Channel
Excite all reps w/Exchan 3
                                                   3: 6
1: If Flag/Port (P91)
                                                   4: 3
                                                   5: 2 Delay (units 0.01 sec) mV Excitation
1: 21 Do if Flag 1 is Low
                                                   5: 2
2: 30
           Then Do
                                                   7: 6
                                                              Loc [ WD
                                                   8: .360
    2: Do (P86)
                                                              Mult
           Set Flag 1 High
    1: 11
                                                   9: 0.0
                                                              Offset
    3: Automatic Setup of TGT1 (P123)
                                                  ;----- Cups
           Address
    1: 12
                                                  ; Read Cups
     2: 10
               Address
                                                  12: Pulse (P3)
                                                   1: 1
     3: 3
               Address
                                                              Reps
     4: 0
              Address
                                                   2: 1
                                                              Pulse Input Channel
                                                   3: 3
     5: 0
               Address
                                                            High Frequency, 16 Bit, All Counts
     6: 2
               Address
                                                   4: 7
                                                             Loc [ WS
                                                                            1
                                                   5: .159744 Mult
     7: 2
               Address
     8: 10
               Address
                                                   6: 0
                                                             Offset
     9: 30
              Assigned Uplink Channel
    10: 0
               Random Uplink Channel
                                                  ;----- Rain
    11: 0
              Self-timed Interval Days
                                                  ; Read CP6 for rain gauge, 0.01" per tip
              Self-timed Interval Hours
    12: 3
                                                  13: Pulse (P3)
                                                   1: 1
    13: 0
               Self-timed Interval Minutes
                                                              Reps
    14: 0
             Self-timed Interval Seconds
                                                   2: 6
                                                              Pulse Input Channel
              Random Interval Hours
Random Interval Minutes
                                                              Switch Closure, All Counts
    15: 0
                                                   3: 2
    16: 0
                                                   4: 8
                                                              Loc [ Rain1_inc ]
              Random Interval Seconds
    17: 0
                                                   5: .01
                                                              Mult
    18: 0
               Initial Self-timed Hours
                                                   6: 0
                                                              Offset
              Initial Self-timed Minutes
    19: 46
    20: 0
               Initial Self-timed Seconds
                                                  ; Add reading to total
               One Minute Window
    21: 0
                                                  14: Z=X+Y (P33)
                                                         X Loc [ Rain1_inc ]
Y Loc [ Rain1 ]
    22: 0
               Short Preamble
                                                   1: 8
    23: 1
               Self-Timed Buffer
                                                   2: 10
                                                            Z Loc [ Rain1
                                                   3: 10
; Identifier for Control Plot is 22
    4: Z=F (P30)
                                                   ; Read CP7 for rain gauge, 0.01" per tip
     1: 22
                                                  15: Pulse (P3)
                                                   1: 1
     2: 0
               Exponent of 10
                                                             Reps
                                                   2: 7
     3: 1
            Z Loc [ Station ]
                                                              Control Port 7
                                                   3: 2
                                                              Switch Closure, All Counts
    5: Z=X+F (P34)
                                                   4: 9
                                                              Loc [ Rain2_inc ]
    1: 1 X Loc [ Station ]
                                                   5: .01
                                                              Mult.
     2: 0.11
               F
                                                              Offset
     3: 19
           Z Loc [ WindID
                                                  ; Add reading to total
    6: Z=X+F (P34)
                                                  16: Z=X+Y (P33)
                                                   3: 20
           Z Loc [ RainID
                             1
    7: Z=X+F (P34)
                                                   ;----- RH
    1: 1 X Loc [ Station
                                                   ; Read the RH voltage (0-1v = 0-100%)
     2: 0.05
                                                  17: Volt (SE) (P1)
               F
                                                   1: 1
                                                           Reps
     3: 21 Z Loc [ DRainID
                                                   2: 5
                                                              2500 mV Slow Range
                                                             SE Channel
    8: Z=X+F (P34)
                                                   3: 4
                                                            Loc [ RH
    1: 1 X Loc [ Station ]
                                                   4: 13
                                                            Mult
     2: 0.16
                                                   5: 0.1
               F
     3: 22
           Z Loc [ TempID
                                                   6: 0
                                                              Offset
                                                  ;---- Temperature
9: Z=X+F (P34)
           X Loc [ Station ]
     1: 1
                                                  ; Read the thermistor
     2: 0.01
             F
                                                  18: Excite-Delay (SE) (P4)
                                                   1: 1 Reps
2: 4 250 mV Slow Range
     3: 18
           Z Loc [ BoxID
                             ]
```

```
3: 3
            SE Channel
                                                     ; Type out both total rain amounts
            Excite all reps w/Exchan 2
                                                     31: Sample (P70)
                                                     1: 2 Reps
2: 10 Loc [ Rain1 ]
5: 0
            Delay (units 0.01 sec)
6: 1000
            mV Excitation
7: 12
            Loc [ Tmister
8: .004
            Mult
9: 0.0
            Offset
                                                     ;---- - Output daily total of Rain
                                                     ; Every day write array 5 with daily rain
; Convert 0.004 mv to Celsius
                                                     32: If time is (P92)
                                                     1: 1140 Minutes (Seconds --) into a
2: 1440 Interval (same units as above)
19: Polynomial (P55)
1: 1
        Reps
           X Loc [ Tmister ]
F(X) Loc [ T_C
2: 12
                                                     3: 10
                                                               Set Output Flag High (Flag 0)
3: 14
4: -37.557 CO
                                                     33: Set Active Storage Area (P80)
5: 430.8
                                                     1: 1 Final Storage Area 1
6: -1441.7 C2
                                                                Array ID
7: 2938.8 C3
                                                     34: Real Time (P77)
8: -3010.4 C4
9: 1200.2 C5
                                                     1: 1110
                                                               Year,Day,Hour/Minute
;----- Solar
                                                     35: Sample (P70)
20: Volt (SE) (P1)
                                                     1: 1
                                                               Reps
1: 1 Reps
                                                     2: 21
                                                                 Loc [ DRainID ]
2: 3
            25 mV Slow Range
3: 7
           SE Channel
                                                     36: Totalize (P72)
4: 15
          Loc [ Solar
                                                     1: 2
                                                               Reps
        Mult
                                                     2: 8
5: 100
                                                                Loc [ Rain1_inc ]
6: 0
           Offset
;----- Output Wind
                                                     ;---- Output T/RH
; Every hour write array 11, WS & WD
                                                     ; Every hour write array 16, T/RH
21: If time is (P92)
                                                     37: If time is (P92)
       Minutes (Seconds --) into a
                                                     1: 0 Minutes (Seconds --) into a
2: 60 Interval (same units as above)
3: 10 Set Output Flag High (Flag 0)
1: 0
           Interval (same units as above)
       Set Output Flag High
3: 10
22: Set Active Storage Area (P80)
                                                     38: Set Active Storage Area (P80)
1: 1 Final Storage Area 1
                                                     1: 1 Final Storage Area 1
2: 16 Array ID
           Array ID
23: Real Time (P77)
                                                     39: Real Time (P77)
1: 1110 Year, Day, Hour/Minute
                                                     1: 1110 Year, Day, Hour/Minute
24: Sample (P70)
                                                     40: Sample (P70)
                                                     1: 1 Reps
2: 22 Loc [ TempID
1: 1 Reps
           Loc [ WindID ]
2: 19
; Write Avg WS, Avg WD, Sigma Theta
                                                     ; Average RH, T, Solar
                                                     41: Average (P71)
25: Wind Vector (P69)
1: 1 Reps
2: 0 Samples per Sub-Interv
3: 00 Sensor/Output Option
4: 7 Wind Speed/East Loc [
                                                           Reps
Loc [ RH
                                                     1: 3
            Samples per Sub-Interval
                                                     2: 13
4: 7 Wind Speed/East Loc [ mb 5 5: 6 Wind Direction/North Loc [ WD ]
                                                     *Table 2 Program
;----- Output 1-hr Rain
                                                     02: 60 Execution Interval (seconds)
; Every hour write array 15 with Rain1 & Rain2
                                                     ; Every minute
26: If time is (P92)
        Minutes (Seconds --) into a
1: 0
                                                     ;---- Signature
2: 60
            Interval (same units as above)
                                                     ; Read the program signature
            Set Output Flag High (Flag 0)
                                                     1: Signature (P19)
3: 10
27: Set Active Storage Area (P80)
                                                     1: 2 Loc [ Sig
1: 1
         Final Storage Area 1
2: 15
                                                     ;----- Battery
           Array ID
                                                     ; Read the battery voltage
28: Real Time (P77)
                                                     2: Batt Voltage (P10)
1: 1110
         Year, Day, Hour/Minute
                                                     1: 3 Loc [ Batt
                                                     ;----- Internal T
29: Sample (P70)
1: 1 Reps
                                                     ; Read internal thermistor
           Loc [ RainID ]
                                                     3: Internal Temperature (P17)
                                                     1: 4 Loc [ Int_T
30: Totalize (P72)
1: 2 Reps
                                                     ;----- Box RH
                                                     4: Volt (SE) (P1)
            Loc [ Rain1_inc ]
                                                     1: 1
                                                                Reps
```

```
2: 5
            2500 mV Slow Range
                                                    ; Minimum of Battery voltage
3: 12
            SE Channel
                                                    11: Minimum (P74)
            Loc [ Int_RH
4: 5
                                                     1: 1 Reps
                                                     2: 0
5: 0.1
                                                                Value Only
            Mult
6: 0.0
            Offset
                                                     3: 3
                                                               Loc [ Batt
;----- Output Sig, AntPower, Batt, T, RH
                                                    ; Average Internal T and RH
; Every hour write the Box variables
                                                    12: Average (P71)
                                                     1: 2
5: If time is (P92)
                                                                Reps
1: 0000
           Minutes (Seconds --) into a
                                                     2: 4
                                                                Loc [ Int_T
2: 60
            Interval (same units as above)
         Set Output Flag High
3: 10
                                                    ;---- Send data to TGT1
                                                    13: If time is (P92)
                                                            Minutes (Seconds --) into a
6: Set Active Storage Area (P80)
                                                    1: 0
1: 1 Final Storage Area 1
                                                     2: 60
                                                                Interval (same units as above)
           Array ID
                                                     3: 30
                                                               Then Do
7: Real Time (P77)
                                                    14: Data Transfer to TGT1 (P120)
1: 1110 Year, Day, Hour/Minute
                                                     1: 000 Binary/Self-Timed/Append
                                                     2: 16
                                                                FWD/Ref Power Loc [ FwdPwr
8: Sample (P70)
           Reps
                                                    15: End (P95)
1: 1
2: 18
           Loc [ BoxID
                                                    ;---- --- Send data to SM716
                                                    16: Serial Out (P96)
; Output Program signature
9: Sample (P70)
                                                     1: 71
                                                               SM192/SM716/CSM1
1: 1
           Reps
2: 2
            Loc [ Sig
                                                    *Table 3 Subroutines
; Output Antenna Power
                                                    End Program
10: Sample (P70)
1: 2 Reps
            Reps
2: 16
            Loc [ FwdPwr
```

Appendix C

FORTRAN code to interpret 3-character data

The following FORTRAN subroutine, named CONVERT, is used to interpret three sequential characters as a numeric value.

```
There are 64 valid characters, ASCII value 63 (?) through ASCII value 126 (~)

?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`abcdefghijklmnopqrstuvwxyz{|}~
```

The IAND function returns the logical product of the two arguments. In other words, the result of the IAND function is a bit-by-bit comparison of the two arguments. The *i*th bit of the result is set to 1 only if the *i*th bits of both arguments is 1.


```
subroutine convert (A, B, C, val, sf)
character*1 A, B, C
IA = iand (ichar(A), 15)
IB = iand (ichar(B), 63)
IC = iand (ichar(C), 63)
val = 0
sf = 1
if (((IA*64)+IB) .ge. 1008) then
      val = (IB-48)*64 + IC + 9000
else
      if (iand(IA,8) .ne. 0) then
             sf = -1
      else
             sf = 1
      endif
      if (iand(IA,4) .ne. 0) sf = sf * 0.01
      if (iand(IA,2) .ne. 0) sf = sf * 0.1
      if (iand(IA,1) .ne. 0) val = 4096
      val = (val + (iand(IB,63)*64) + iand(IC,63)) * sf
endif
return
end
```


Appendix D


Monthly Plots of Hourly Data


- A. Wind Speed
- B. Wind Direction
- C. Air temperature
- D. Relative humidity
- E. Box RH
- F. Cumulative rainfall
- G. Incoming sunlight (Starting April 2001)


A. Wind Speed




























B. Wind Direction





8/1/00

8/6/00


8/11/00


8/16/00


8/21/00


8/26/00


8/31/00




























C. Air temperature































D. Relative humidity






















E. Box RH





































F. Cumulative rainfal

























































































G. Incoming sunlight (Starting April 2001)



Appendix E

Monthly Tables of Daily Rainfall

May 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
5/10/00	0	0	0	0	0	0	0	0
5/11/00	0	0	0	0	0	0	0	0
5/12/00	0	0	0	0	0	0	0	0
5/13/00	0	0	0	0	0	0	0	0
5/14/00	0	0	0	0	0	0	0	0
5/15/00	0	0	0	0	0	0	0	0
5/16/00	0	0	0	0	0	0	0	0
5/17/00	0.25	0.25	0.21	0.24	0.13	0.15	0.26	0.24
5/18/00	0	0	0	0	0	0	0.01	0.00
5/19/00	0.15	0.14	0.13	0.13	0.84	0.87	0.09	0.13
5/20/00	0.48	0.47	0.46	0.45	0.16	0.17	0.60	0.49
5/21/00	0	0	0	0	0	0	0	0
5/22/00	0	0	0	0	0	0	0	0
5/23/00	0	0	0	0	0	0	0	0
5/24/00	0	0	0	0	0	0	0	0
5/25/00	0	0	0	0	0	0	0	0
5/26/00	0.06	0.06	0.04	0.04	0	0	0	0.04
5/27/00	0	0	0	0	0	0	0	0
5/28/00	0	0	0	0	0	0	0	0
5/29/00	0	0	0	0	0	0	0	0
5/30/00	0	0	0	0	0	0	0	0
5/31/00	0.03	0.03	0	0	0	0	0	0.01
5/2000 totals	0.97	0.95	0.84	0.86	1.13	1.19	0.96	0.92

June 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
6/1/00	0.01	0.01	0.03	0.04	0	0	0	0.02
6/2/00	0	0	0	0	0	0	0	0
6/3/00	0	0	0	0	0	0	0	0
6/4/00	0.03	0.03	0.05	0.04	0.03	0.03	0	0.03
6/5/00	0	0	0	0	0	0	0	0
6/6/00	0	0	0	0	0	0	0	0
6/7/00	0	0	0	0	0	0	0	0
6/8/00	0.01	0.01	0	0	0.20	0.23	0	0.00
6/9/00	0.01	0.01	0	0	0	0	0	0.00
6/10/00	0.03	0.02	0.03	0.03	0.09	0.09	0	0.02
6/11/00	0.21	0.19	0.17	0.19	0.01	0.02	0.40	0.23
6/12/00	0	0	0	0	0.01	0.02	0	0
6/13/00	0	0	0	0	0.03	0.02	0	0
6/14/00	0.45	0.45	0.43	0.45	0.37	0.40	0.86	0.53
6/15/00	0.02	0.02	0.01	0.01	0.02	0.02	0.03	0.02
6/16/00	0	0	0	0	0.01	0.01	0	0
6/17/00	0	0	0	0	0	0	0	0
5/18/00	0	0	0	0	0	0	0	0
6/19/00	0.25	0.24	0.41	0.35	0	0	0.27	0.30
6/20/00	0	0	0.27	0	0.01	0.01	0	0.05
6/21/00	0	0	0	0	0	0	0	0
6/22/00	0	0	0	0	0	0	0	0
6/23/00	0	0	0	0	0	0	0	0
6/24/00	0	0	0	0	0.01	0.01	0	0
6/25/00	0	0	0	0	0	0	0	0
6/26/00	0	0	0	0	0	0	0	0
6/27/00	0	0	0	0	0	0	0	0
6/28/00	0.06	0.06	0.05	0.04	0	0	0.05	0.05
6/29/00	0	0	0	0	0	0	0	0
6/30/00	0.01	0.01	0.01	0.01	0	0	0	0.01
6/2000 totals	1.08	1.04	1.43	1.12	0.79	0.86	1.61	1.26

July 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
7/1/00	0.42	0.39	0.41	0.39	0.23	0.24	0.40	0.40
7/2/00	0.03	0.01	0.02	0.02	0.17	0.17	0.05	0.03
7/3/00	0	0	0	0	0	0	0	0
7/4/00	0.33	0.33	0.31	0.29	0.20	0.22	0.33	0.32
7/5/00	0.04	0.03	0.01	0.02	0.06	0.06	0.08	0.04
7/6/00	0.05	0.04	0.04	0.03	0.02	0.03	0	0.03
7/7/00	0	0	0	0	0.01	0	0.06	0.01
7/8/00	0	0	0	0	0	0	0	0
7/9/00	5.64	5.46	4.91	5.10	3.49	3.46	4.61	5.14
7/10/00	0	0	0	0	0	0	1.10	0.22
7/11/00	0.01	0.01	0.01	0	0	0	0.03	0.01
7/12/00	0	0	0	0	0	0	0	0
7/13/00	0.07	0.06	0.06	0.05	0	0	0.02	0.05
7/14/00	0.12	0.11	0.11	0.11	0.24	0.27	0.20	0.13
7/15/00	0.42	0.40	0.39	0.46	0.08	0.07	0.10	0.35
7/16/00	0.01	0	0	0.01	0.01	0.01	0.35	0.07
7/17/00	0	0	0.01	0	0.21	0.23	0.01	0.00
7/18/00	1.91	1.87	1.92	1.82	0.83	0.88	1.80	1.86
7/19/00	0	0	0.04	0	0	0	0	0.01
7/20/00	0	0	0	0	0	0	0.01	0.00
7/21/00	0.01	0.01	0.02	0.03	0	0	0	0.01
7/22/00	0.29	0.28	0.28	0.26	0.39	0.40	0.30	0.28
7/23/00	0	0	0.01	0	0	0	0.02	0.01
7/24/00	0.28	0.27	0.20	0.20	0.02	0.03	0.29	0.25
7/25/00	0	0	0	0	0	0	0	0
7/26/00	0.17	0.16	0.31	0.16	0.25	0.27	0.17	0.19
7/27/00	0.04	0.04	0.05	0.02	0.01	0.01	0.07	0.04
7/28/00	0	0	0	0	0	0	0	0
7/29/00	0.02	0.01	0.02	0.01	0.11	0.12	0.02	0.02
7/30/00	0.10	0.11	0.02	0.08	0.01	0.01	0.12	0.09
7/31/00	0.02	0.01	0	0	0.04	0.04	0	0.01
7/2000 totals	9.98	9.60	9.15	9.06	6.38	6.52	10.14	9.59

August 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
8/1/00	0	0	0.07	0.01	0	0	0.01	0.02
8/2/00	0.08	0.07	0.18	0.16	0	0	0.10	0.12
8/3/00	0	0	0	0	0	0	0.01	0.00
8/4/00	0.04	0.03	0.05	0.07	0	0	0	0.04
8/5/00	0.03	0.03	0.03	0.04	0.62	0.67	0.08	0.04
8/6/00	0.63	0.61	n/a*	n/a*	0.14	0.16	0.65	0.63
8/7/00	1.87	1.86	n/a*	n/a*	4.31	4.38	1.85	1.86
8/8/00	0	0	n/a*	n/a*	0	0.01	0.06	0.02
8/9/00	0.10	0.09	n/a*	n/a*	0	0	0	0.06
8/10/00	0	0.01	n/a*	n/a*	0	0	0.12	0.04
8/11/00	0.06	0.05	n/a*	n/a*	0.48	0.51	0.07	0.06
8/12/00	0	0	n/a*	n/a*	0	0	0	0
8/13/00	0.01	0	n/a*	n/a*	0.01	0	0	0.00
8/14/00	1.20	1.18	n/a*	n/a*	0.91	0.96	0.03	0.80
8/15/00	0	0	n/a*	n/a*	0	0	1.20	0.40
8/16/00	0.30	0.28	n/a*	n/a*	0.02	0.02	0	0.19
8/17/00	0	0	n/a*	n/a*	0	0	0.33	0.11
8/18/00	0	0	n/a*	n/a*	0.06	0.06	0	0
8/19/00	0.07	0.07	n/a*	n/a*	0	0	0.08	0.07
8/20/00	0.42	0.42	n/a*	n/a*	0.46	0.50	0.25	0.36
8/21/00	0.28	0.26	n/a*	n/a*	0.04	0.04	0.48	0.34
8/22/00	0.06	0.07	n/a*	n/a*	0.06	0.07	0.10	0.08
8/23/00	0	0	n/a*	n/a*	0	0	0	0
8/24/00	0	0	n/a*	n/a*	0	0	0	0
8/25/00	0.02	0.02	n/a*	n/a*	0.09	0.10	0	0.01
8/26/00	0.36	0.35	n/a*	n/a*	0.68	0.69	0.39	0.37
8/27/00	0	0	n/a*	n/a*	0	0	0.01	0.00
8/28/00	0.28	0.26	n/a*	n/a*	0.43	0.47	0	0.18
8/29/00	0.74	0.73	n/a*	n/a*	0.47	0.47	0.79	0.75
8/30/00	0.72	0.71	n/a*	n/a*	0.32	0.34	1.00	0.81
8/31/00	0	0	n/a*	n/a*	0	0	0	0
8/2000 totals	7.27	7.10	0.33	0.28	9.10	9.45	7.61	7.38

^{*} Incomplete data from the House 36 station.

September 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
9/1/00	0.04	0.04	n/a*	n/a*	0	0	0	0.03
9/2/00	0	0	n/a*	n/a*	0	0	0.05	0.02
9/3/00	0.12	0.11	n/a*	n/a*	0	0	0.01	0.08
9/4/00	0.10	0.10	n/a*	n/a*	0	0	0.22	0.14
9/5/00	0.02	0.02	n/a*	n/a*	0.55	0.56	0.05	0.03
9/6/00	0	0	n/a*	n/a*	0	0	0.03	0.01
9/7/00	0.09	0.08	n/a*	n/a*	0	0	0	0.06
9/8/00	0.04	0.04	n/a*	n/a*	0.21	0.22	0.10	0.06
9/9/00	0.01	0	n/a*	n/a*	0	0	0.05	0.02
9/10/00	0.02	0.03	n/a*	n/a*	0	0	n/a*	0.03
9/11/00	0.04	0.03	0.04	0.05	0	0	0.08	0.05
9/12/00	0.01	0.01	0	0.01	0.26	0.27	0.02	0.01
9/13/00	0.76	0.75	0.80	0.74	0.73	0.74	0.76	0.76
9/14/00	0.11	0.10	0.24	0.07	0	0	0.10	0.12
9/15/00	0.10	0.09	0.41	0.18	0	0	0.16	0.19
9/16/00	0.05	0.05	0.04	0.06	0	0	0.06	0.05
9/17/00	0	0	0	0	0	0	0	0
9/18/00	0.65	0.63	0.63	0.63	0	0	0	0.51
9/19/00	0	0	0	0	0	0	0.66	0.13
9/20/00	0.17	0.16	0.07	0.05	0	0	0.03	0.10
9/21/00	0.08	0.07	0.03	0.03	0	0	0.25	0.09
9/22/00	0	0	0	0	0.42	0.45	0.01	0.00
9/23/00	0	0	0	0	0	0	0	0
9/24/00	0	0	0	0	0	0	0	0
9/25/00	0	0	0	0	0	0	0	0
9/26/00	0.06	0.06	0.04	0.13	0	0	0.05	0.07
9/27/00	0.09	0.08	0.02	0.06	0	0	0.12	0.07
9/28/00	0.27	0.26	0.31	0.27	0.84	0.83	0.29	0.28
9/29/00	0.12	0.12	0.13	0.20	0.01	0.01	0.01	0.12
9/30/00	0.03	0.02	0	0.01	0	0	0.13	0.04
9/2000 totals	2.98	2.85	2.76	2.49	3.02	3.08	3.24	3.06

 $[\]ensuremath{^*}$ Incomplete data from the House 36 station.

October 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
10/1/00	0	0	0	0	0.09	0.09	0.04	0.01
10/2/00	0.11	0.11	0.12	0.07	0	0	0	0.08
10/3/00	0.02	0.01	0.01	0.02	0.03	0.03	0.12	0.04
10/4/00	0.03	0.03	0	0.02	0.05	0.06	0.05	0.03
10/5/00	0	0	0	0	0	0	0	0
10/6/00	0	0	0	0	0.18	0.19	0	0
10/7/00	0.12	0.12	0.14	0.09	0.29	0.28	0	0.09
0/8/00	0.22	0.21	0.18	0.21	0	0	0.34	0.23
10/9/00	0.26	0.24	0.18	0.18	0.39	0.41	0.08	0.19
10/10/00	0.40	0.41	0.33	0.34	0.18	0.19	0.67	0.43
0/11/00	0	0	0	0	0	0	0	0
10/12/00	0	0	0	0	0.20	0.24	0	0
10/13/00	0	0	0	0	0	0.01	0	0
10/14/00	0.01	0.01	0.01	0.01	0	0	0.01	0.01
10/15/00	0.09	0.07	0.09	0.10	0	0	0	0.07
10/16/00	0.29	0.29	0.27	0.25	0.30	0.33	0.40	0.30
10/17/00	0.24	0.23	0.22	0.24	0	0	0.23	0.23
0/18/00	0.24	0.23	0.22	0.19	0.32	0.35	0.07	0.19
0/19/00	0.25	0.25	0.25	0.26	0.44	0.43	0.49	0.30
0/20/00	0.34	0.33	0.20	0.23	0	0	0.34	0.29
0/21/00	0	0	0	0	0	0	0	0
0/22/00	0.04	0.04	0.04	0.07	0	0	0.05	0.05
10/23/00	0	0	0	0	0.56	0.59	0	0
0/24/00	0	0	0	0	0	0.01	0	0
0/25/00	0	0	0	0	0	0	0	0
10/26/00	0.23	0.22	0.67	0.22	0	0	0.22	0.31
10/27/00	0.52	0.50	0.48	0.51	0.75	0.75	0.03	0.41
0/28/00	0.18	0.17	0.26	0.22	0	0	0.58	0.28
0/29/00	0	0	0	0	0	0	0	0
10/30/00	0.93	0.90	0.79	0.91	1.29	1.32	0.77	0.86
10/31/00	0.78	0.78	0.76	0.71	0.24	0.24	1.09	0.82
10/2000 totals	5.30	5.15	5.22	4.85	5.31	5.52	5.58	5.22

November 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
11/1/00	0.16	0.16	0.17	0.15	0.19	0.21	0.11	0.15
11/2/00	0.32	0.32	0.25	0.25	0.34	0.34	0.24	0.28
11/3/00	0.11	0.11	0.13	0.11	0.28	0.30	0.31	0.15
11/4/00	0	0	0.02	0.02	0.01	0.02	0	0.01
11/5/00	0	0	0.03	0.02	0	0	0.01	0.01
11/6/00	0	0	0	0	0.04	0.04	0	0
11/7/00	0.55	0.55	0.51	0.44	0	0.01	0.15	0.44
11/8/00	0	0	0	0	0.05	0.05	0.40	0.08
11/9/00	0.04	0.03	0.05	0.07	0	0	0	0.04
11/10/00	0.02	0.02	0.03	0.03	0	0	0.05	0.03
11/11/00	0.12	0.12	0.07	0.07	0	0	0.04	0.08
11/12/00	0.04	0.04	0.05	0.03	0	0	0.19	0.07
11/13/00	0	0	0	0	0.12	0.13	0.01	0.00
11/14/00	0.09	0.09	0.04	0.04	0.04	0.05	0.01	0.05
11/15/00	0.01	0.01	0.04	0.05	0	0	0.10	0.04
11/16/00	0	0	0	0	0	0	0.01	0.00
11/17/00	0.04	0.03	0.03	0.03	0.23	0.26	n/a ^a	0.03
11/18/00	0.25	0.25	0.25	0.24	0.11	0.12	0.30	0.26
11/19/00	0.53	0.52	0.85	0.63	0.27	0.30	0.55	0.62
11/20/00	0	0	0	0	0.04	0.05	0.03	0.01
11/21/00	0	0	0	0	0.07	0.07	0.01	0.00
11/22/00	0.04	0.04	0.03	0.03	0.09	0.12	0.02	0.03
11/23/00	0.33	0.31	0.40	0.38	0.26	0.29	0.37	0.36
11/24/00	3.22	3.16	3.16	3.04	2.51	2.47	1.75	2.87
11/25/00	2.45	2.42	2.53	2.29	0.54	0.54	4.15	2.77
11/26/00	1.67	1.65	1.68	1.64	0	0	0.42	1.41
11/27/00	2.55	2.51	2.51	2.52	2.12	2.17	3.95	2.81
11/28/00	0.09	0.10	0.12	0.11	0	0	0.16	0.12
11/29/00	0.30	0.28	0.25	0.24	0.49	0.51	0.40	0.29
11/30/00	0.56	0.53	0.50	0.49	n/a ^b	n/a ^b	0.57	0.53
11/2000 totals	13.49	13.25	13.70	12.92	7.98	8.24	14.31	13.54

 $^{^{\}rm a}$ $\,$ Manual gauge rainfall noted on 11/18/00 (0.30") includes rain occurring on 11/17/00.

b Incomplete data from the Eneu station.

December 2000 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
12/1/00	0.14	0.15	0.09	0.11	n/a*	n/a*	0.02	0.10
12/2/00	0.80	0.75	0.72	0.67	n/a*	n/a*	0.30	0.65
12/3/00	0	0	0	0.01	n/a*	n/a*	0.66	0.13
12/4/00	0	0	0	0	n/a*	n/a*	0	0
12/5/00	0.09	0.10	0.09	0.10	n/a*	n/a*	0	0.08
12/6/00	0.31	0.29	0.29	0.29	n/a*	n/a*	0.40	0.32
12/7/00	0.04	0.04	0.06	0.07	n/a*	n/a*	0.06	0.05
12/8/00	0	0	0	0	n/a*	n/a*	0	0
12/9/00	0	0	0	0	n/a*	n/a*	0	0
12/10/00	0	0	0	0	n/a*	n/a*	0	0
12/11/00	0.01	0.01	0.02	0.02	n/a*	n/a*	0.02	0.02
12/12/00	0	0	0	0	n/a*	n/a*	0	0
12/13/00	0	0	0	0	n/a*	n/a*	0	0
12/14/00	0	0	0	0	n/a*	n/a*	0	0
12/15/00	0.11	0.10	0.04	0.07	n/a*	n/a*	0.02	0.07
12/16/00	0.02	0.02	0.03	0.03	n/a*	n/a*	0.15	0.05
12/17/00	0	0.01	0	0	n/a*	n/a*	0.02	0.01
12/18/00	0.02	0.02	0	0	n/a*	n/a*	0.02	0.01
12/19/00	0	0	0	0	n/a*	n/a*	0	0
12/20/00	0	0	0	0	n/a*	n/a*	0	0
12/21/00	0.34	0.34	0.33	0.32	n/a*	n/a*	0.40	0.35
12/22/00	0	0	0	0	n/a*	n/a*	0.01	0.00
12/23/00	0.28	0.26	0.27	0.23	n/a*	n/a*	0.30	0.27
12/24/00	0.03	0.02	0.02	0.03	n/a*	n/a*	0.07	0.03
12/25/00	0	0	0	0	n/a*	n/a*	0	0
12/26/00	0	0	0	0	n/a*	n/a*	0	0
12/27/00	0	0	0	0	n/a*	n/a*	0	0
12/28/00	0.12	0.12	0.08	0.11	n/a*	n/a*	0.07	0.10
12/29/00	0	0	0	0	n/a*	n/a*	0.10	0.02
12/30/00	0.19	0.19	0.17	0.24	n/a*	n/a*	0.01	0.16
12/31/00	0.09	0.10	0.13	0.13	n/a*	n/a*	0.34	0.16
12/2000 totals	2.59	2.52	2.34	2.43	n/a*	n/a*	2.97	2.57

 $[\]ensuremath{^{\star}}$ Incomplete data from the Eneu station.

January 2001 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
1/1/01	0	0	0	0	n/a*	n/a*	0	0
1/2/01	0	0	0	0	n/a*	n/a*	0	0
1/3/01	0	0	0	0	n/a*	n/a*	0.01	0.00
1/4/01	0	0	0	0	n/a*	n/a*	0	0
1/5/01	0	0	0	0	n/a*	n/a*	0	0
1/6/01	0	0	0	0	n/a*	n/a*	0	0
1/7/01	0	0	0	0	n/a*	n/a*	0	0
1/8/01	0.01	0.01	0	0	n/a*	n/a*	0	0.00
1/9/01	0	0	0	0	n/a*	n/a*	0.02	0.00
1/10/01	0	0	0	0	n/a*	n/a*	0	0
1/11/01	0	0	0	0	n/a*	n/a*	0	0
1/12/01	0.02	0.02	0.01	0.02	n/a*	n/a*	0.05	0.02
1/13/01	0	0	0	0	n/a*	n/a*	0.01	0.00
1/14/01	0	0	0	0	n/a*	n/a*	0	0
1/15/01	0	0	0	0	n/a*	n/a*	0.01	0.00
1/16/01	0.46	0.45	0.38	0.39	n/a*	n/a*	0.47	0.43
1/17/01	0	0	0	0	n/a*	n/a*	0.01	0.00
1/18/01	0	0	0	0	n/a*	n/a*	0	0
1/19/01	0	0	0	0	n/a*	n/a*	0	0
1/20/01	0	0	0	0	n/a*	n/a*	0.01	0.00
1/21/01	0	0	0	0	n/a*	n/a*	0	0
1/22/01	0	0	0	0	n/a*	n/a*	0	0
1/23/01	0.22	0.21	0.14	0.21	n/a*	n/a*	0	0.16
1/24/01	0	0	0	0	n/a*	n/a*	0.22	0.04
1/25/01	0	0	0	0	n/a*	n/a*	0	0
1/26/01	0	0	0	0	n/a*	n/a*	0	0
1/27/01	0	0	0	0	n/a*	n/a*	0	0
1/28/01	0.01	0	0.02	0.01	n/a*	n/a*	0	0.01
1/29/01	0	0	0	0	n/a*	n/a*	0.02	0.00
1/30/01	0.22	0.23	0.19	0.20	n/a*	n/a*	0.15	0.20
1/31/01	0.17	0.16	0.10	0.12	n/a*	n/a*	0.12	0.13
1/2001 totals	1.11	1.08	0.84	0.95	n/a*	n/a*	1.10	1.02

^{*} Incomplete data from the Eneu station.

February 2001 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
2/1/01	0	0	0	0	n/a*	n/a*	0.06	0.01
2/2/01	0.05	0.04	0.06	0.06	n/a*	n/a*	0.01	0.04
2/3/01	0.01	0.01	0	0	n/a*	n/a*	0.06	0.02
2/4/01	0	0	0	0	n/a*	n/a*	0.01	0.00
2/5/01	0	0	0	0	n/a*	n/a*	0	0
2/6/01	0.01	0.01	0	0	n/a*	n/a*	0.01	0.01
2/7/01	0	0	0	0	n/a*	n/a*	0	0
2/8/01	0	0	0	0	n/a*	n/a*	0	0
2/9/01	0	0	0	0	n/a*	n/a*	0	0
2/10/01	0.01	0.01	0	0	n/a*	n/a*	0.02	0.01
2/11/01	0.02	0.01	0	0.01	n/a*	n/a*	0.01	0.01
2/12/01	0	0	0	0	n/a*	n/a*	0	0
2/13/01	0	0	0	0	n/a*	n/a*	0	0
2/14/01	0.05	0.05	0.02	0.02	n/a*	n/a*	0.05	0.04
2/15/01	0	0	0	0	n/a*	n/a*	0	0
2/16/01	0.07	0.06	0.06	0.05	n/a*	n/a*	0.03	0.05
2/17/01	0.01	0.02	0.04	0.02	n/a*	n/a*	0.07	0.03
2/18/01	0.15	0.15	0.14	0.13	n/a*	n/a*	0	0.11
2/19/01	0.12	0.11	0.07	0.09	n/a*	n/a*	0.31	0.14
2/20/01	0	0	0	0	n/a*	n/a*	0	0
2/21/01	0	0	0	0	n/a*	n/a*	0	0
2/22/01	0.08	0.07	0.10	0.08	n/a*	n/a*	0.08	0.08
2/23/01	0	0	0	0	n/a*	n/a*	0	0
2/24/01	0	0	0	0	n/a*	n/a*	0	0
2/25/01	0.02	0.02	0.05	0.03	n/a*	n/a*	0.02	0.03
2/26/01	1.53	1.48	1.35	1.41	n/a*	n/a*	0.92	1.34
2/27/01	0	0	0	0	n/a*	n/a*	0.63	0.13
2/28/01	0	0	0	0	n/a*	n/a*	0	0
2/2001 totals	2.13	2.04	1.89	1.90	n/a*	n/a*	2.29	2.05

 $[\]ensuremath{^{\star}}$ Incomplete data from the Eneu station.

March 2001 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
3/1/01	0	0	0	0	n/a*	n/a*	0	0
3/2/01	0	0	0	0	n/a*	n/a*	0	0
3/3/01	0.06	0.05	0.06	0.06	n/a*	n/a*	0.08	0.06
3/4/01	0.01	0.02	0	0	n/a*	n/a*	0.02	0.01
3/5/01	0	0	0	0	n/a*	n/a*	0	0
3/6/01	0.06	0.05	0.06	0.10	n/a*	n/a*	0	0.05
3/7/01	0	0.01	0	0	n/a*	n/a*	0.03	0.01
3/8/01	0.06	0.06	0.05	0.06	n/a*	n/a*	0.05	0.06
3/9/01	0	0	0	0	n/a*	n/a*	0	0
3/10/01	0	0	0	0	n/a*	n/a*	0.07	0.01
3/11/01	0	0	0	0	n/a*	n/a*	0	0
3/12/01	0	0	0	0	n/a*	n/a*	0	0
3/13/01	0.04	0.05	0.03	0.05	n/a*	n/a*	0.06	0.05
3/14/01	0.31	0.29	0.29	0.29	n/a*	n/a*	0.20	0.28
3/15/01	0.04	0.04	0.05	0.04	n/a*	n/a*	0.19	0.07
3/16/01	0	0	0	0	n/a*	n/a*	0	0
3/17/01	0.01	0.01	0	0	n/a*	n/a*	0	0.00
3/18/01	0	0	0	0	n/a*	n/a*	0	0
3/19/01	0	0	0	0	n/a*	n/a*	0	0
3/20/01	0	0	0	0	n/a*	n/a*	0.02	0.00
3/21/01	0	0	0	0	n/a*	n/a*	0	0
3/22/01	0	0	0	0	n/a*	n/a*	0	0
3/23/01	0	0	0	0	n/a*	n/a*	0	0
3/24/01	0	0	0	0	n/a*	n/a*	0	0
3/25/01	0.04	0.04	0	0.01	n/a*	n/a*	0	0.02
3/26/01	0	0	0	0	n/a*	n/a*	0.05	0.01
3/27/01	0	0	0	0	n/a*	n/a*	0	0
3/28/01	0.01	0.01	0	0	n/a*	n/a*	0	0.00
3/29/01	0.07	0.08	0.06	0.06	n/a*	n/a*	0.04	0.06
3/30/01	0	0	0	0	n/a*	n/a*	0.06	0.01
3/31/01	0	0	0	0	n/a*	n/a*	0	0
3/2001 totals	0.71	0.71	0.60	0.67	n/a*	n/a*	0.87	0.71

^{*} Incomplete data from the Eneu station.

April 2001 Bikini Atoll Rain (inches)

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
4/1/01	0.02	0.02	0.03	0.01	n/a*	n/a*	0.04	0.02
4/2/01	0.31	0.30	0.39	0.37	n/a*	n/a*	0.33	0.34
4/3/01	0.03	0.03	0	0	n/a*	n/a*	n/a*	0.02
4/4/01	0.07	0.07	0.04	0.04	n/a*	n/a*	0.13	0.07
4/5/01	0	0	0	0	0	0	0	0
4/6/01	0.04	0.05	0.05	0.02	0	0	0.04	0.04
1/7/01	0	0	0.01	0.01	0	0.01	0	0.00
4/8/01	0.03	0.04	0.01	0.01	0	0	0.03	0.02
1/9/01	0	0	0	0	0	0	0	0
4/10/01	0	0	0	0	0.01	0	0	0
1/11/01	0	0	0	0	0	0	0	0
1/12/01	0.05	0.04	0.09	0.05	0.05	0.06	0	0.05
1/13/01	0.01	0.02	0	0.01	0.01	0	0	0.01
1/14/01	0.02	0.02	0.05	0.04	0	0	0.07	0.04
1/15/01	0.01	0.01	0.08	0.08	0.01	0.01	0.02	0.04
1/16/01	0.08	0.08	0.05	0.06	0	0	0	0.05
1/17/01	0	0	0	0	0	0	0.13	0.03
1/18/01	0	0	0	0	0	0	0	0
1/19/01	0	0	0	0	0	0	0	0
1/20/01	0	0	0	0	0	0	0.01	0.00
1/21/01	0	0	0	0	0.01	0	0	0
1/22/01	0	0	0	0	0	0	0	0
1/23/01	0	0	0	0	0	0	0	0
4/24/01	0	0	0	0	0	0	0	0
1/25/01	0	0	0	0	0	0	0	0
1/26/01	0.29	0.30	0.27	0.26	0.08	0.09	0.32	0.29
1/27/01	0.01	0	0	0	0	0.01	0.01	0.00
1/28/01	0	0	0	0	0	0	0	0
1/29/01	0	0	0	0	0	0	0	0
4/30/01	0.01	0.01	0.01	0	0	0	0.03	0.01
4/2001 totals	0.98	0.99	1.08	0.96	0.17	0.18	1.16	1.03

 $[\]mbox{\ensuremath{^{\ast}}}$ Incomplete data from the Eneu station.

Appendix F

Historical Monthly Totals of Rainfall

Bikini Atoll historical monthly rain (inches).

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
7/1985	4.14	*		*	*	*	4.08	4.11
8/1985	7.72	*	*	*	*	*	7.83	7.78
9/1985	7.86	*	*	*	*	*	7.73	7.80
10/1985	6.68	*	*	*	*	*	6.58	6.63
11/1985	4.18	*	*	*	*	*	4.29	4.24
12/1985	3.08	*	*	*	*	*	2.99	3.04
1/1986	3.72	*	*	*	*	*	3.73	3.73
2/1986	0.19	*	*	*	*	*	0.20	0.20
3/1986	1.13	*	*	*	*	*	1.14	1.14
4/1986	1.83	*	*	*	*	*	1.88	1.86
5/1986	4.52	*	*	*	*	*	7.85	6.19
6/1986	3.75	*	*	*	*	*	5.80	4.78
7/1986	*	*	*	*	*	*	6.92	6.92
•	*	*	*	*	*	*	16.57	16.57
8/1986 9/1986	*	*	*	*	*	*	16.39	16.39
•	*	*	*	*	*	*		
10/1986	*	*	*	*	*	*	9.76	9.76
11/1986	*	*	*	*	*	*	6.90	6.90
12/1986							4.91	4.91
1/1987	*	*	*	*	*	*	0.68	0.68
2/1987	*	*	*	*	*	*	0.73	0.73
3/1987	*	*	*	*	*	*	0.69	0.69
4/1987	*	*	*	*	*	*	3.18	3.18
5/1987	*	*	*	*	*	*	0.60	0.60
6/1987	*	*	*	*	*	*	1.55	1.55
7/1987	*	*	*	*	*	*	4.44	4.44
8/1987	*	*	*	*	*	*	7.23	7.23
9/1987	*	*	*	*	*	*	6.53	6.53
10/1987	*	*	*	*	*	*	7.55	7.55
11/1987	*	*	*	*	*	*	8.63	8.63
12/1987	*	*	*	*	*	*	3.17	3.17
1/1988	*	*	*	*	*	*	1.95	1.95
2/1988	*	*	*	*	*	*	0.80	0.80
3/1988	*	*	*	*	*	*	1.39	1.39
4/1988	*	*	*	*	*	*	0.98	0.98
5/1988	*	*	*	*	*	*	1.22	1.22
6/1988	*	*	*	*	*	*	8.67	8.67
7/1988	*	*	*	*	*	*	7.47	7.47
8/1988	*	*	*	*	*	*	5.27	5.27
9/1988	*	*	*	*	*	*	9.52	9.52
10/1988	*	*	*	*	*	*	7.17	7.17
11/1988	*	*	*	*	*	*	4.66	
11/1988	*	*	*	*	*	*	4.66 1.74	4.66 1.74
	*	*	*	*	*	*	1.74 1.69	
1/1989	*	*	*	*	*	*		1.69
2/1989	*	*	*	*	*	*	2.17	2.17
3/1989		*				*	2.07	2.07
4/1989	*		*	*	*		2.69	2.69
5/1989	*	*	*	*	*	*	5.40	5.40
6/1989	*	*	*	*	*	*	12.02	12.02
7/1989	*	*	*	*	*	*	14.04	14.04
8/1989	*	*	*	*	*	*	10.22	10.22
9/1989	*	*	*	*	*	*	10.29	10.29
10/1989	*	*	*	*	*	*	4.11	4.11

Bikini Atoll historical monthly rain (inches) (continued).

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
11/1989	*	*	*	*	*	*	5.49	5.49
12/1989	*	*	*	*	*	*	1.68	1.68
1/1990	*	*	*	*	2.40	*	3.79	3.79
2/1990	*	*	*	*	2.07	*	3.23	3.23
3/1990	*	*	*	*	12.12	*	9.49	9.49
4/1990	1.42	1.27	1.40	1.36	1.66	*	1.62	1.44
5/1990	3.09	2.80	2.88	3.21	3.11	*	3.43	3.11
6/1990	7.52	6.98	7.42	8.04	3.95	*	8.23	7.58
7/1990	13.12	11.77	11.04	11.69	15.33	*	13.54	12.81
8/1990	*	*	5.64	6.00	6.80	*	6.93	6.93
9/1990	15.31	14.49	14.65	14.89	10.45	*	16.02	15.27
10/1990	*	*	7.54	8.22	10.28	*	8.94	8.94
11/1990	*	*	18.70	20.26	15.20	*	20.88	20.88
12/1990	*	7.16	7.55	8.22	5.03	*	8.15	7.66
1/1991	*	0.77	0.72	0.87	0.82	*	1.46	1.12
2/1991	2.04	2.06	2.12	2.40	1.74	*	2.34	2.15
3/1991	3.43	3.45	*	3.78	2.64	*	4.39	3.76
, 4/1991	5.18	5.27	*	5.89	5.31	*	6.19	5.55
5/1991	2.31	2.29	*	2.32	2.61	*	2.75	2.45
6/1991	*	*	*	2.23	2.62	*	2.09	2.09
7/1991	*	*	*	3.77	3.57	*	4.40	4.40
8/1991	10.86	10.30	*	11.26	8.09	*	12.50	11.22
9/1991	6.98	7.18	*	7.47	9.13	*	7.88	7.35
10/1991	16.60	16.47	*	18.37	8.51	*	18.95	17.34
11/1991	8.48	8.76	*	10.26	9.52	*	8.36	8.53
12/1991	2.09	2.25	*	2.56	1.56	*	2.67	2.34
1/1992	1.08	1.25	*	1.48	1.80	*	1.94	1.42
2/1992	0.68	0.81	*	0.88	0.80	*	1.33	0.94
3/1992	1.66	1.94	*	2.21	2.17	*	2.37	1.99
4/1992	0.52	0.49	*	0.63	1.57	*	*	0.51
5/1992	0.35	0.39	0.25	0.39	0.92	*	*	0.37
6/1992	2.34	2.23	2.28	2.67	1.33	*	3.64	2.74
7/1992	2.52	2.38	2.64	2.88	1.96	*	3.29	2.73
8/1992	8.28	8.04	7.99	8.55	11.29	*	8.92	8.41
9/1992	7.53	7.15	8.31	8.08	6.42	*	7.06	7.25
10/1992	11.57	10.52	12.75	12.90	8.40	*	13.38	11.82
11/1992	15.84	*	*	*	12.73	*	14.60	15.22
12/1992	2.40	2.11	2.59	2.64	4.25	*	2.84	2.45
1/1993	0.98	0.89	0.84	0.91	3.84	*	1.08	0.98
2/1993	0.46	0.37	0.40	0.45	0.40	*	0.61	0.48
3/1993	0.41	0.39	0.33	0.39	0.10	*	0.75	0.52
4/1993	0.50	0.48	*	*	1.03	*	0.59	0.52
5/1993	0.85	0.43	*	*	1.04	*	0.61	0.76
6/1993	1.79	1.14	*	*	0.86	*	1.64	1.52
7/1993	7.13	1.1 1 *	*	*	4.56	*	7.37	7.25
8/1993	7.13	*	6.95	6.86	5.66	*	7.37	7.23
9/1993	9.32	8.89	10.15	10.57	7.78	*	8.54	8.92
10/1993	10.56	9.88	9.96	9.79	11.37	*	10.42	10.29
11/1993	*	9.00 *	9.90 *	9.79 *	*	*	14.26	14.26
12/1993	*	*	*	*	*	*	7.84	7.84
1/1994		0.64	0.69	0.69	*	*	0.89	0.73
	0.66				*	*		
2/1994	0.22	0.23	0.17	0.18		*	0.40	0.28

Bikini Atoll historical monthly rain (inches) (continued).

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
3/1994	0.64	0.61	0.71	0.68	*	*	0.89	0.71
4/1994	2.14	2.03	2.04	2.19	*	*	2.30	2.16
5/1994	2.32	2.13	2.34	2.51	*	*	2.47	2.31
6/1994	*	*	9.38	10.72	7.31	*	9.99	9.99
7/1994	*	*	8.77	10.51	7.36	*	11.34	11.34
8/1994	*	*	*	*	*	*	4.63	4.63
9/1994	*	*	*	*	*	*	14.05	14.05
10/1994	*	*	8.02	8.83	2.03	*	10.49	10.49
11/1994	*	*	5.23	5.27		*	6.62	6.62
12/1994	4.03	2.98	3.56	3.98	6.73	*	4.35	3.79
1/1995	1.18	1.12	1.22	1.22	0.54	*	1.79	1.36
2/1995	0.11	0.11	0.18	0.15	0.05	*	0.20	0.14
3/1995	1.17	1.07	1.00	1.08	1.13	*	1.57	1.27
4/1995	4.08	3.84	3.90	4.19	2.66	*	4.58	4.17
5/1995	8.25	*	7.95	8.24	*	*	8.20	8.23
6/1995	1.59	1.36	1.60	1.62	2.59	*	2.02	1.66
7/1995	6.05	5.42	5.83	5.77	5.85	*	6.92	6.13
8/1995	8.97	8.32	9.04	8.88	*	*	9.29	8.86
9/1995	5.72	5.35	5.44	5.62	*	*	6.43	5.83
10/1995	9.70	8.72	9.66	10.05	*	*	9.80	9.41
11/1995	4.72	4.44	4.65	4.62	*	*	5.44	4.87
12/1995	0.90	0.93	0.90	0.88	*	*	1.54	1.12
1/1996	3.12	2.93	3.20	3.39	*	*	3.60	3.22
2/1996	3.02	2.84	2.74	3.06	*	*	3.11	2.99
3/1996	4.25	3.41	4.27	4.53	*	*	5.30	4.32
4/1996	1.62	1.15	1.54	1.59	*	*	2.09	1.62
5/1996	0.64	0.61	0.63	0.63	*	*	0.82	0.69
6/1996	*	*	*	*	*	*	7.36	7.36
7/1996	6.03	5.54	5.42	6.25	*	*	7.13	6.23
8/1996	5.76	4.63	5.09	5.77	*	*	7.19	5.86
9/1996	10.37	7.77	9.44	10.57	*	*	11.40	9.85
10/1996	6.98	5.62	6.10	6.54	*	*	8.03	6.88
11/1996	*	*	*	*	*	*	12.02	12.02
12/1996	*		*	*	*	*	*5.47	5.47
1/1997	1.82	1.08	1.91	1.91		*	2.06	2.06
2/1997	1.51	1.42	2.21	2.27	*	*	2.44	2.44
3/1997	11.46	7.84	11.43	12.15			12.60	12.60
4/1997	6.23	5.66	6.48	6.82	*	*	6.85	6.85
5/1997	9.58	8.50	4.96	8.95	*	*	10.61	10.61
6/1997	4.14	3.56	2.83	4.06	*	*	3.35	3.35
7/1997	3.16	2.65	2.27	3.10	*	*	3.99	3.99
8/1997	18.13	15.55	15.21	18.48	*	*	19.16	19.16
9/1997	17.26	15.15	15.01	18.74			18.95	18.95
10/1997	7.62	6.60	5.57	8.20	*	*	7.78	7.78
11/1997	2.50	2.08	1.99	2.55	*	*	2.87	2.87
12/1997	3.88	3.23	3.20	3.79	*	*	4.61	4.61
1/1998	1.37	1.23	0.91	1.35	*	*	1.96	1.96
2/1998	0.74	0.63	0.40	0.70	*	*	1.24	1.24
3/1998	0.98	0.84	0.55	0.90	*	*	1.42	1.42
4/1998	1.69	1.40	1.44	1.74	*	*	2.16	2.16
5/1998	0.70	0.58	0.46	0.55	*	*	0.64	0.64
6/1998	3.73	2.27	2.65	3.40	*	*	3.93	3.93
7/1998	3.84	3.18	3.58	3.92	×	×	4.58	4.58

Bikini Atoll historical monthly rain (inches) (continued).

Date	CP South	CP North	H36 Plot	H36 Tower	Eneu West	Eneu East	Manual gage	Bikini Isle average
8/1998	3.09	2.09	2.71	2.90	*	*	3.61	3.61
9/1998	5.44	4.13	4.86	5.40	*	*	6.54	6.54
10/1998	6.45	3.65	*		*	*	8.26	8.26
11/1998	5.79	4.19	*	1.78	*	*	6.59	6.59
12/1998	1.53	1.14	*	1.55	*	*	2.55	2.55
1/1999	1.66	0.81	*	1.65	*	*	2.27	2.27
2/1999	0.47	0.20	*	0.35	*	*	0.83	0.83
3/1999	0.60	0.39	*	0.54	*	*	1.51	1.51
4/1999	1.02	0.65	*	0.88	*	*	1.37	1.37
5/1999	2.82	1.96	*	*	*	*	1.49	1.49
6/1999	1.02	2.04	*	*	*	*	3.57	3.57
7/1999	4.19	1.21	*	*	*	*	5.22	5.22
8/1999	2.14	*	*	*	*	*	2.88	2.88
9/1999	6.33	*	*	*	*	*	7.14	7.14
10/1999	4.77	3.30	2.03	2.62	*	*	4.72	4.72
11/1999	6.77	6.90	5.23	6.66	*	*	7.22	7.22
12/1999	0.43	0.43	0.29	0.48	*	*	0.99	0.99
1/2000	*	*	*	*	*	*	0.88	0.88
2/2000	*	*	*	*	*	*	2.56	2.56
3/2000	*	*	*	*	*	*	1.13	1.13
4/2000	*	*	*	*	*	*	0.93	0.93
5/2000	0.98	0.96	0.87	0.90	1.13	1.19	0.96	0.92
6/2000	1.50	1.43	1.84	1.51	1.01	1.08	1.61	1.27
7/2000	9.56	9.21	8.81	8.68	6.16	6.30	10.14	9.59
8/2000	7.31	7.14	*	*	9.10	9.45	7.61	7.38
9/2000	2.94	2.81	2.76	2.49	3.02	3.08	3.24	3.05
10/2000	5.46	5.31	5.37	5.00	5.41	5.64	5.58	5.22
11/2000	13.46	13.23	13.42	12.75	8	*	14.31	13.34
12/2000	2.46	2.38	2.25	2.32	*	*	2.97	2.57
1/2001	1.11	1.08	0.84	0.95	*	*	1.10	1.02
2/2001	2.13	2.04	1.89	1.90	*	*	2.29	2.05
3/2001	0.73	0.73	0.62	0.68	*	*	0.87	0.71
4/2001	0.98	0.98	1.07	0.97	*	*	1.16	1.03

^{*} Incomplete data.

Appendix G

Wind Rose Tables

These wind rose tables are made from Bikini Atoll data takes from 9 May 2000 through 30 April 2001. All available data was included in the statistics. Wind speed classes are based on the integer portion of the wind speed. For example, the wind speed class 0 includes wind speeds from 0 to 0.999 m/s; class 1 includes speeds from 1.0 to 1.999 m/s. The wind direction classes are centered on the indicated direction.

The wind rose diagrams are created from the data in the tables. The roses group the wind speed classes into 5 groups: Calms, 1 to 2.999 m/s, 3 to 3.999, 4 to 4.999, and 5.0 and greater. The calms are distributed evenly among all 16 wind direction classes.

Control Plot N	=8439		Wind Speed Class							
Wind from	Total	0	1	2	3	4	5	6	7	8
S	0%	32	40	1	0	0	0	0	0	0
SSE	0%	48	14	4	0	0	0	0	0	0
SE	1%	86	79	38	2	1	0	0	0	0
ESE	6%	83	256	173	36	4	1	0	0	0
E	25%	64	407	1120	527	48	1	0	0	0
ENE	47%	65	404	1871	1478	201	4	0	0	0
NE	9%	57	160	414	174	16	0	0	0	0
NNE	1%	59	71	11	0	0	0	0	0	0
N	0%	108	19	3	0	0	0	0	0	0
NNW	0%	20	1	0	0	0	0	0	0	0
NW	0%	41	2	0	0	0	0	0	0	0
WNW	0%	19	7	2	0	0	0	0	0	0
W	0%	13	12	0	0	0	0	0	0	0
WSW	0%	9	13	0	0	0	0	0	0	0
SW	0%	7	24	1	0	0	0	0	0	0
SSW	1%	30	58	0	0	0	0	0	0	0
	Total	9%	19%	43%	26%	3%	0%	0%	0%	0%
Cum	ulative	9%	27%	70%	97%	100%	100%	100%	100%	100%

Eneu N=3567	7		Win	d Speed C	lass					
Wind from	Total	0	1	2	3	4	5	6	7	8
S	0%	5	8	5	0	1	0	0	0	0
SSE	1%	5	16	5	1	0	0	0	0	0
SE	1%	5	23	20	5	3	0	0	0	0
ESE	2%	5	16	23	14	8	1	0	1	0
E	5%	8	28	77	62	15	2	0	0	0
ENE	31%	9	40	305	593	149	6	1	0	0
NE	41%	11	96	309	681	312	52	12	0	0
NNE	11%	22	81	138	90	55	18	23	0	0
N	2%	42	25	27	20	2	7	0	0	0
NNW	1%	2	10	5	5	0	0	0	0	0
NW	0%	2	3	0	2	0	0	0	0	0
WNW	0%	3	4	0	0	0	0	0	0	0
W	0%	2	12	1	2	0	0	0	0	0
WSW	0%	0	1	0	0	0	0	0	0	0
SW	0%	9	2	5	0	0	0	0	0	0
SSW	0%	4	3	1	1	0	0	0	0	0
C	Total Cumulative	4% 4%	10% 14%	26% 40%	41% 81%	15% 97%	2% 99%	1% 100%	0% 100%	0% 100%
				10 10						
House 36 N=	6638		Win	d Speed C	lass					
Wind from	Total	0	1	2	3	4	5	6	7	8
S	1%	3	16	14	3	1	0	0	0	0
SSE	0%	6	10	7	3	1	3	0	0	0
SE	1%	11	17	20	18	6	2	0	0	0
ESE	7%	21	26	76	155	132	44	1	0	0
E	41%	28	43	261	790	1107	462	40	0	0
ENE	21%	29	42	158	494	530	156	12	0	0
NE	6%	30	55	120	143	88	2	0	0	0
NNE	10%	54	102	155	230	164	8	1	0	0
N	7%	64	51	114	176	97	5	0	0	0
NNW	0%	10	19	3	3	0	0	0	0	0
NW	1%	2	10	21	12	1	0	0	0	0
WNW	0%	1	4	8	11	2	1	0	0	0
W	1%	4	8	19	13	2	0	0	0	0
WSW	0%	3	10	11	4	0	0	0	0	0
SW	0%	1	9	7	1	0	0	0	0	0
SSW	0%	4	16	10	1	0	0	0	0	0
C	Total Cumulative	4% 4%	7% 11%	15% 26%	31% 57%	32% 89%	10% 99%	1% 100%	0% 100%	0% 100%

University of California Lawrence Livermore National Laboratory Technical Information Department Livermore, CA 94551